




Buzdolabı
Kullanma Kılavuz



BÜRO TİPİ
SR-2513

TR-ENG

simfer

İÇİNDEKİLER

| | | |
|----------|---|----|
| 1 | Güvenlik uyarıları | |
| 1.1 | Uyarı | 3 |
| 1.2 | Güvenlik uyarı sembollerinin anlamları | 5 |
| 1.3 | Elektrikle ilgili uyarılar | 5 |
| 1.4 | Kullanım uyarıları | 6 |
| 1.5 | Yerleştirme için uyarılar | 6 |
| 1.6 | Enerji için uyarılar | 7 |
| 1.7 | İmha için uyarılar | 7 |
| 2 | Buzdolabının uygun şekilde kullanımı | |
| 2.1 | Yerleştirme | 8 |
| 2.2 | Dengeleme ayakları | 9 |
| 2.3 | Kapı Sağ-Sol Değişimi | 10 |
| 2.4 | Işığın Değiştirilmesi (isteğe bağlı) | 12 |
| 2.5 | Kullanmaya başlamak | 12 |
| 2.6 | Enerji tasarrufu ipuçları | 12 |
| 3 | Yapısı ve işlevleri | |
| 3.1 | Temel bileşenler | 13 |
| 3.2 | İşlevleri | 14 |
| 4 | Buzdolabının bakımı | |
| 4.1 | Temizlik | 15 |
| 4.2 | Buz çözme | 15 |
| 4.3 | Faaliyet dışı | 16 |
| 5 | Sorun Giderme | |
| 5.1 | Sorun Giderme | 17 |

1 Güvenlik Uyarıları

1.1 Uyarı



Uyarı: yangın riski / yanıcı maddeler

Bu cihaz, mağazalardaki, ofislerdeki ve diğer çalışma ortamlarındaki personel mutfak alanları; çiftlik evleri ve otellerdeki, motellerdeki ve diğer konut tipi ortamlardaki müşteriler tarafından; yatak ve kahvaltı tipi ortamlar; catering ve benzeri perakende olmayan uygulamalar gibi ev ve benzeri uygulamalarda kullanılmak üzere tasarlanmıştır.

Bu cihaz, güvenliklerinden sorumlu bir kişi tarafından gözetim altında tutulmadıkları veya cihazın kullanımıyla ilgili talimat verilmediği sürece, fiziksel, duyuşsal veya zihinsel yetenekleri sınırlı olan veya deneyim ve bilgi eksikliği olan kişiler (çocuklar dahil) tarafından kullanılmak üzere tasarlanmamıştır).

Çocuklar, cihazla oynamadıklarından emin olmak için gözetim altında tutulmalıdır.

Eğer besleme kablosu hasar görürse, bir tehlikeyi önlemek için üretici, servis temsilcisi veya benzer kalifiye kişiler tarafından değiştirilmelidir.

Yanıcı itici gaz içeren aerosol kutuları gibi patlayıcı maddeleri bu cihazda saklamayın.

Kullanımdan sonra ve cihaz üzerinde kullanıcı bakımı yapmadan önce cihazın fişi çekilmelidir.

Uyarı: Cihaz muhafazasındaki veya ankastre yapıdaki havalandırma açıklıklarını engellerden uzak tutun.

Uyarı: Buz çözme işlemini hızlandırmak için üretici tarafından tavsiye edilenler dışında mekanik cihazlar veya başka araçlar kullanmayın.

Uyarı: Soğutucu gaz devresine zarar vermeyin.

Uyarı: Üretici tarafından tavsiye edilen tipte olmadıkça, cihazın gıda saklama bölmelerinin içinde elektrikli aletler kullanmayın.

Uyarı: Yanıcı üfleme gazı ve soğutucu gaz kullanması nedeniyle lütfen buzdolabını yerel regülatörlere uygun olarak bırakınız.

Uyarı: Cihazı yerleştirirken, besleme kablosunun sıkışmadığından veya hasar görmediğinden emin olun.

Uyarı: Cihazın arkasına birden fazla taşınabilir priz veya taşınabilir güç kaynağı yerleştirmeyin.

Uzatma kabloları veya topraklanmamış (iki uçlu) adaptörler kullanmayın.

Tehlike: Çocuk sıkışması riski. Eski buzdolabınızı veya dondurucunuzu atmadan önce:

- Kapıları çıkarın.

-Çocukların kolayca içeri tırmanmaması için rafları yerinde bırakın.

Aksesuar takmaya başlamadan önce buzdolabının elektrik kaynağı ile bağlantısı kesilmelidir.

Cihaz için kullanılan soğutucu akışkan ve siklopentan köpük malzemesi yanıcıdır. Bu nedenle, cihaz hurdaya çıkarıldığında, herhangi bir ateş kaynağından uzak tutulmalı ve çevreye zarar vermesini veya başka herhangi bir zararı önlemek için yanma yoluyla imha edilmesinin dışında ilgili niteliklere sahip özel bir geri kazanım şirketi tarafından geri kazanılmalıdır.

Kilit ve anahtarlarla donatılmış kapı veya kapaklarda, çocukların içeride kilitle kalmasını önlemek için anahtarların çocukların erişemeyeceği bir yerde ve soğutucu cihazın yakınında bulundurulması gerekliliği.

EN standardı için: Bu cihaz, 8 yaş ve üzeri çocuklar ve fiziksel duyuşsal veya zihinsel yetenekleri azalmış veya deneyim ve bilgi eksikliği olan kişiler tarafından, cihazın güvenli bir şekilde kullanılmasına ilişkin gözetim veya talimat verildiği ve ilgili tehlikeleri anladıkları takdirde kullanılabilir. Çocuklar cihaz ile oynamamalıdır. Temizlik ve kullanıcı bakımı gözetim olmadan çocuklar tarafından yapılmamalıdır. 3 ila 8 yaş arası çocukların soğutucu cihazları yüklemelerine ve boşaltmalarına izin verilir.

Gıdaların kontaminasyonunu önlemek için lütfen aşağıdaki talimatlara uyun:

- Kapağın uzun süre açılması, cihazın bölmelerindeki sıcaklığın önemli ölçüde artmasına neden olabilir.
- Gıda ile temas edebilecek yüzeyleri ve erişilebilir drenaj sistemlerini düzenli olarak temizleyin.
- Su tanklarını 48 saat boyunca kullanılmamışlarsa temizleyin; 5 gün boyunca su çekilmemişse bir su kaynağına bağlı su sistemini yıkayın. (not 1)
- Çiğ et ve balığı, diğer yiyeceklerle temas etmeyecek veya üzerine damlamayacak şekilde buzdolabında uygun kaplarda saklayın.
- İki yıldızlı dondurulmuş gıda bölmeleri önceden dondurulmuş gıdaları saklamak, dondurma saklamak veya yapmak ve buz küpleri yapmak için uygundur. (not 2)
- Bir, iki ve üç yıldızlı bölmeler taze gıdaların dondurulması için uygun değildir (not 3)
- 4 yıldızlı bölmesi olmayan cihazlar için: Bu soğutucu cihaz gıda maddelerinin dondurulması için uygun değildir. (not 4)
- Soğutucu cihaz uzun süre boş bırakılırsa, cihaz içinde küf oluşumunu önlemek için kapatın, buzunu çözün, temizleyin, kurulaşın ve kapıyı açık bırakın.

Not 1,2,3,4: Lütfen ürün bölmesi tipinize göre geçerli olup olmadığını onaylayın.

Bağımsız bir cihaz için: Bu soğutucu cihaz ankastre bir cihaz olarak kullanılmak üzere tasarlanmamıştır.




LED lambaların değiştirilmesi veya bakımının üretici, servis temsilcisi veya benzeri kalifiye bir kişi tarafından yapılması amaçlanmıştır. (Lamba değişimi için bölüm 2.4'e bakın)

UYARI: Cihazın dengesizliğinden kaynaklanan bir tehlikeyi önlemek için, talimatlara uygun olarak sabitlenmelidir.

UYARI: Sadece içilebilir su kaynağına bağlayın. (Buz yapma makinesi için uygundur)



Bir Çocuğun Sıkışmasını Önlemek İçin, Çocukların Ulaşamayacağı Yerde Tutun ve Dondurucunun (Veya Buzdolabının) Çevresinde Bulundurmayın." (Kilitli ürünler için uygundur)

1.2 Güvenlik uyarı sembollerinin anlamı

| | |
|---|--|
|  | <p>Bu bir yasaklama sembolüdür. Bu sembole işaretlenmiş talimatlara uyulmaması ürünün hasar görmesine veya kullanıcının kişisel güvenliğinin tehlikeye girmesine neden olabilir.</p> |
|  | <p>Bu bir uyarı sembolüdür. Bu sembole işaretlenmiş talimatlara tam olarak uyularak çalıştırılması gerekir; aksi takdirde üründe hasar veya kişisel yaralanma meydana gelebilir.</p> |
|  | <p>Bu bir dikkat sembolüdür. Bu sembole işaretlenmiş talimatlar özel dikkat gerektirir. Yetersiz dikkat hafif veya orta derecede yaralanmaya veya ürünün hasar görmesine neden olabilir.</p> |


Bu kılavuz, kullanıcılar tarafından uyulması gereken birçok önemli güvenlik bilgisi içermektedir.

1.3 Elektrikle ilgili uyarılar




- Buzdolabının elektrik fişini çekerken güç kablosunu çekmeyin. Lütfen fişi sıkıca kavrayın ve doğrudan prizden çekin.
- Güvenli kullanım sağlamak için güç kablosuna zarar vermeyin veya güç kablosunu hasarlı veya yıpranmış halde kullanmayın.
- Lütfen özel bir elektrik prizi kullanın ve elektrik prizi diğer elektrikli cihazlarla paylaşılmamalıdır. Elektrik fişi prize sıkıca temas ettirilmelidir, aksi takdirde yangın çıkabilir.
- Lütfen elektrik prizinin topraklama elektrodunun güvenilir bir topraklama hattı ile donatıldığından emin olun.
- Gaz ve diğer yanıcı gazların sızması durumunda lütfen sızan gazın vanasını kapatın ve ardından kapı ve pencereleri açın. Kıvılcımın yangına neden olabileceğini düşünerek buzdolabının ve diğer elektrikli cihazların fişini çekmeyiniz.
- Üretici tarafından tavsiye edilen tipte olmadıkça, elektrikli aletleri cihazın üstünde kullanmayın.

1.4 Kullanım ile ilgili uyarılar



- Buzdolabını gelişigüzel sökmeyin veya tekrar kurmayın ya da soğutucu akışkan devresine zarar vermeyin; cihazın bakımı bir uzman tarafından yapılmalıdır
- Hasarlı güç kablosu, tehlikeyi önlemek için üretici, bakım departmanı veya ilgili profesyoneller tarafından değiştirilmelidir.



- Buzdolabı kapıları arasındaki ve kapılar ile buzdolabı gövdesi arasındaki boşluklar küçüktür, parmağınızın sıkışmasını önlemek için elinizi bu alanlara koymamaya dikkat edin. Eşyaların düşmesini önlemek için buzdolabının kapısını kapatırken lütfen nazik olun.
- Buzdolabı çalışırken dondurma bölümündeki yiyecekleri veya kapıları, özellikle donmayı önlemek için metal kapıları ıslak ellerle almayınız.




- Hiçbir çocuğun buzdolabına girmesine veya tırmanmasına izin vermeyin; aksi takdirde çocuğun boğulmasına veya düşerek yaralanmasına neden olabilir.




- Kapıyı kapatırken veya açarken nesnelerin düşebileceğini ve kazara yaralanmalara neden olabileceğini göz önünde bulundurarak buzdolabının üstüne ağır nesnelere koymayın.
- Elektrik kesintisi veya temizlik durumunda lütfen fişi çekin. Arka arkaya çalıştırma nedeniyle kompresörün zarar görmesini önlemek için buzdolabını beş dakika içinde güç kaynağına bağlamayın.


1.5 Yerleştirme ile ilgili uyarılar



- Ürünün zarar görmesini veya yangın kazalarını önlemek için buzdolabına yanıcı, patlayıcı, uçucu ve yüksek derecede aşındırıcı maddeler koymayın.
- Yangınları önlemek için yanıcı maddeleri buzdolabının yakınına koymayın.



- Buzdolabı, gıdaların saklanması gibi ev kullanımı için tasarlanmıştır; kan, ilaç veya biyolojik ürünlerin saklanması gibi başka amaçlar için kullanılmamalıdır.



- Şişelerde veya kapalı kaplarda bulunan bira, meşrubat veya diğer sıvıları buzdolabının dondurma bölümünde saklamayın; aksi takdirde şişeler veya kapalı kaplar donma nedeniyle çatlayarak hasara neden olabilir.

1.6 Enerji ile ilgili uyarılar

Enerji ile ilgili uyarı

- 1) Soğutucu cihazlar, soğutucu cihazın tasarlandığı sıcaklık aralığının soğuk ucunun altına uzun bir süre yerleştirildiğinde tutarlı çalışmayabilir (içindekilerin buzunun çözülmesi veya donmuş gıda bölümünde sıcaklığın çok yükselmesi olasılığı).
- 2) Köpüren içeceklerin gıda dondurucu bölmelerinde veya dolaplarında veya düşük sıcaklık bölmelerinde veya dolaplarında saklanmaması gerektiği ve su buzları gibi bazı ürünlerin çok soğuk tüketilmemesi gerektiği gerçeği;
- 3) Gıda dondurucu ve dondurulmuş gıda saklama bölmelerinde veya dolaplarında her türlü gıda için ve özellikle ticari olarak hızlı dondurulmuş gıdalar için gıda üreticileri tarafından önerilen saklama sürelerinin aşılması gerektiği
- 4) Dondurulmuş gıdanın birkaç kat gazete kağıdına sarılması gibi, soğutucu cihazın buzunu çözerken dondurulmuş gıdanın sıcaklığının aşırı yükselmesini önlemek için gerekli önlemler.
- 5) Manuel buz çözme, bakım veya temizlik sırasında dondurulmuş gıdanın sıcaklığındaki artışın saklama ömrünü kısaltabileceği gerçeği.

1.7 İmha ile ilgili uyarılar

Buzdolabı için kullanılan soğutucu akışkan ve siklopentan köpük malzemesi yanıcıdır. Bu nedenle, buzdolabı hurdaya çıkarıldığında, herhangi bir ateş kaynağından uzak tutulmalı ve çevreye zarar vermesini veya başka herhangi bir zararı önlemek için yakılarak imha edilmesi dışında uygun niteliklere sahip özel bir geri kazanım şirketi tarafından geri kazanılmalıdır.



Buzdolabı hurdaya çıkarıldığında, kapıları sökün ve kapı ve rafların contasını çıkarın; kapıları ve rafları herhangi bir çocuğun sıkışmasını önleyecek şekilde uygun bir yere koyun.




Bu ürünün Doğru İmhası:


Bu işaret, bu ürünün diğer evsel atıklarla birlikte atılmaması gerektiğini gösterir. Kontrolsüz atık imhasının çevreye veya insan sağlığına olası zararlarını önlemek için, malzeme kaynaklarının sürdürülebilir yeniden kullanımını teşvik etmek amacıyla sorumlu bir şekilde geri dönüştürün. Kullanılmış cihazınızı iade etmek için lütfen iade ve toplama sistemlerini kullanın veya ürünün satın alındığı perakendeciyle iletişime geçin. Bu ürünün çevresel açıdan güvenli geri dönüşümü için alabilirler.

2 Buzdolaplarının doğru kullanımı


2.1 Yerleştirme




- Kullanmadan önce, buzdolabının içindeki alt yastıklar, köpük pedler ve bantlar dahil olmak üzere tüm ambalaj malzemelerini çıkarın; kapılar ve buzdolabı gövdesi üzerindeki koruyucu filmi yırtın.



- Isıdan uzak tutun ve doğrudan güneş ışığından kaçının. Paslanmayı veya yalıtım etkisinin azalmasını önlemek için dondurucuyu nemli veya sulu yerlere yerleştirmeyin.
- Buzdolabının elektrik yalıtım özelliklerini etkilememek için buzdolabını püskürtmeyin veya yıkamayın; buzdolabını su sıçraması kolay nemli yerlere koymayın.



- Buzdolabı iyi havalandırılan kapalı bir yere yerleştirilir; zemin düz ve sağlam olmalıdır (dengesizse tekerleği düzeltmek için sola veya sağa döndürerek ayarlayın).



- Buzdolabının üst boşluğu 30 cm'den fazla olmalı ve ısı dağılımını kolaylaştırmak için buzdolabı 10 cm'den fazla serbest mesafeye sahip bir duvara yerleştirilmelidir.




Kurulumdan önce alınacak önlemler:

Aksesuarları takmadan veya ayarlamadan önce buzdolabının elektrik bağlantısının kesildiğinden emin olunmalıdır.

Tutamağın düşerek herhangi bir kişisel yaralanmaya neden olmasını önlemek için önlemler alınmalıdır.

2.2 Dengeleme ayakları

Dengeleme ayaklarının şematik diyagramı



(Yukarıdaki resim sadece referans içindir. Gerçek konfigürasyon fiziksel ürüne veya distribütör tarafından yapılan açıklamaya bağlı olacaktır)

Ayarlama prosedürleri:


- Buzdolabını yükseltmek için ayakları saat yönünde çevirin;
- Buzdolabını indirmek için ayakları saat yönünün tersine çevirin;
- Yukarıdaki prosedürlere göre sağ ve sol ayakları yatay bir seviyeye ayarlayın.

2.3 Kapının Sağa Sola Değişimi


| Kullanıcı tarafından tedarik edilecek aletlerin listesi | | | |
|---|--------------------------|---|--|
|  | Yıldız tornavida |  | Macun bıçağı ince uçlu tornavida |
|  | 5116" soket ve mandal |  | Maskeleme bandı |

| Kapının ters yöne çevrilmesinde kullanılacak parçalar | | | |
|---|--------------------------------|------|---|
| Numara | Adı | Adet | Not |
| 1 | Üst menteşe | 1 | Buzdolabına önceden monte edilmiştir, kapı ters çevrildiğinde hala kullanılır |
| 2 | Menteşe kapağı | 1 | Buzdolabına önceden monte edilmiştir, kapı ters çevrildiğinde hala kullanılır |
| 3 | Kılavuz çekme kilitleme vidası | 5 | Buzdolabına önceden monte edilmiştir, kapı ters çevrildiğinde hala kullanılır |
| 4 | Delik kapağı | 1 | Buzdolabına önceden monte edilmiştir, kapı ters çevrildiğinde hala kullanılır |
| 5 | Pim | 2 | Buzdolabına önceden monte edilmiştir, kapı ters çevrildiğinde hala kullanılır |
| 6 | Alt menteşe grubu | 1 | Buzdolabına önceden monte edilmiştir, kapı ters çevrildiğinde hala kullanılır |
| 7 | Dengeleme ayağı | 1 | Buzdolabına önceden monte edilmiştir, kapı ters çevrildiğinde hala kullanılır |
| 8 | Durdurucu | 1 | Buzdolabına önceden monte edilmiştir, kapı ters çevrildiğinde hala kullanılır |
| 8 | Kılavuz çekme vidası | 1 | Buzdolabına önceden monte edilmiştir, kapı ters çevrildiğinde hala kullanılır |

- 1) Buzdolabını kapatın ve kapı tepsilerindeki tüm nesnelere çıkarın.
- 2) Üst menteşe kapağını, üst menteşeyi ve diğer tarafın delik kapağını sökün, durdurucu kapısını çıkarın.




- 3) Önce kapıyı sökün, ardından alt menteşe grubunu ve dengeleme ayağını çıkarın, alt menteşe grubunun ve dengeleme ayağının konumlarını değiştirin ve takın.




(Yukarıdaki resim sadece referans içindir. Gerçek konfigürasyon fiziksel ürüne veya distribütör tarafından yapılan açıklamaya bağlı olacaktır)

- 4) Kapının altındaki durdurucuyu sökün, ardından diğer taraftaki durdurucuyu monte edin.



- 5) Kapıyı alt menteşe grubuna takın ve ardından üst menteşeyi, menteşe kapağını, pimleri ve delik kapağını sırayla takın.





(Yukarıdaki resim sadece referans içindir. Gerçek konfigürasyon fiziksel ürüne veya distribütör tarafından yapılan açıklamaya bağlı olacaktır)

2.4 Işığın Değiştirilmesi (isteğe bağlı)

LED lambaların değiştirilmesi veya bakımının üretici, servis temsilcisi veya benzeri kalifiye bir kişi tarafından yapılması amaçlanmıştır. Değiştirme işlemi için önce güç kaynağı kesilmelidir.

(Yukarıdaki içerik sadece referans içindir. Gerçek yapılandırma fiziksel ürüne veya distribütör tarafından yapılan açıklamaya bağlı olacaktır)

2.5 Kullanmaya başlama




- İlk çalıştırmadan önce, güç kaynağına bağlamadan önce buzdolabını yarım saat hareketsiz tutun.
- Herhangi bir taze veya dondurulmuş gıda koymadan önce, buzdolabı 2-3 saat veya ortam sıcaklığının yüksek olduğu yaz aylarında 4 saatten fazla çalışmış olmalıdır.
- Kapıların ve çekmecelerin rahatça açılabilmesi veya distribütör tarafından beyan edilebilmesi için yeterli alan ayırın.

2.6 Enerji tasarrufu ipuçları

- Cihaz odanın en serin yerine, ısı üreten aletlerden veya ısıtma kanallarından uzağa ve doğrudan güneş ışığından uzak bir yere yerleştirilmelidir.
- Sıcak yiyecekleri cihaza yerleştirmeden önce oda sıcaklığına soğumasını bekleyin. Cihazın aşırı yüklenmesi kompresörü daha uzun süre çalışmaya zorlar. Çok yavaş donan gıdalar kalitesini kaybedebilir veya bozulabilir.
- Gıdaları cihaza yerleştirmeden önce düzgün bir şekilde sardığınızdan ve kapları kurulduğunuzdan emin olun. Bu, cihazın içinde don birikmesini azaltır.
- Cihaz saklama bölümü alüminyum folyo, yağlı kağıt veya kağıt havlu ile kaplanmamalıdır.
- Astarlar soğuk hava dolaşımını engelleyerek cihazın daha az verimli olmasını sağlar.
- Kapı açıklıklarını ve uzun aramaları azaltmak için yiyecekleri düzenleyin ve etiketleyin. Tek seferde gerektiği kadar ürünü çıkarın ve kapıyı mümkün olan kısa sürede kapatın.

3 Yapısı ve işlevleri

3.1 Temel bileşenler




(Yukarıdaki resim sadece referans içindir. Gerçek konfigürasyon fiziksel ürüne veya distribütör tarafından yapılan açıklamaya bağlı olacaktır)

Soğutucu bölme

- Soğutucu Bölme, kısa vadede tüketilen çeşitli meyve, sebze, içecek ve diğer yiyeceklerin saklanması için uygundur. 3 gün ila 5 gün arasında önerilen saklama süresi.
- Yiyecekleri yukarıdaki resimde gösterilen pozisyonda yerleştirmek verimli enerji kullanımını sağlar.
- Yiyeceklerin buzdolabına konulmadan önce kapatılması tavsiye edilir.
- Şişelenmiş veya konserve içeceklerin ve diğer öğelerin kapının üzerine konulması önerilir;

Not: İlk güç bağlantısından sonra çalışma sırasında çok fazla yiyecek depolanması buzdolabının dondurma etkisini olumsuz etkileyebilir. Depolanan yiyecekler hava çıkışını engellemelidir; aksi takdirde dondurma etkisi de olumsuz etkilenecektir.

3.2 İşlevleri (1)



(Yukarıdaki resim sadece referans içindir. Gerçek konfigürasyon fiziksel ürüne veya distribütör tarafından yapılan açıklamaya bağlı olacaktır)

- Sıcaklık kontrol düğmesini MAX'a çevirin, buzdolabının iç sıcaklığı düşer.
- Sıcaklık kontrol düğmesini MIN'e çevirin, buzdolabının iç sıcaklığı yükselir.
- Düğme üzerindeki harf sadece seviyeyi temsil eder, ancak belirli bir sıcaklık anlamına gelmez, "OFF" çalışmayı durdurma anlamına gelir
- Önerilen seviye: "MED".
- Özel bir ihtiyaç yoksa, tank mesanesinin buzlanmasını önleyebildiğinizden emin olmak için lütfen vitesi her zaman MAX olarak ayarlamaktan kaçının.

Buzdolabının bakımı

4.1 Temizlik

- Soğutma etkisini iyileştirmek ve enerji tasarrufu sağlamak için buzdolabının arkasındaki ve yerdeki tozlar zamanında temizlenmelidir.
- Kalıntı olmadığından emin olmak için kapı contasını düzenli olarak kontrol edin. Kapı contasını sabunlu su veya seyreltilmiş deterjanla ıslatılmış yumuşak bir bezle temizleyin.
- Kokuyu önlemek için buzdolabının içi düzenli olarak temizlenmelidir.
- Lütfen iç kısmı temizlemeden önce gücü kapatın, tüm yiyecekleri, içecekleri, rafları, çekmeceleri vb. çıkarın.
- Buzdolabının içini temizlemek için iki yemek kaşığı karbonat ve bir litre ılık su ile yumuşak bir bez veya sünger kullanın. Ardından suyla durulayın ve silerek temizleyin. Temizlikten sonra kapıyı açın ve gücü açmadan önce doğal olarak kurumasını bekleyin.
- Buzdolabında temizlenmesi zor alanlar için (dar sandviçler, boşluklar veya köşeler gibi), bu alanlarda kirletici veya bakteri birikmemesini sağlamak için yumuşak bir bez, yumuşak fırça vb. ile ve gerektiğinde bazı yardımcı araçlarla (ince çubuklar gibi) birlikte düzenli olarak silinmesi önerilir.
- Sabun, deterjan, ovma tozu, sprey temizleyici vb. kullanmayın, çünkü bunlar buzdolabının iç kısmında kokuya veya kirlenmiş yiyeceklere neden olabilir.
- Şişe çerçevesini, rafları ve çekmeceleri sabunlu su veya seyreltilmiş deterjanla ıslatılmış yumuşak bir bezle temizleyin. Yumuşak bir bezle kurulayın veya doğal yollarla kurutun.
- Buzdolabının dış yüzeyini sabunlu su, deterjan vb. ile ıslatılmış yumuşak bir bezle silin ve ardından kurulayın.
- Buzdolabının yüzeyine ve iç kısmına zarar verebilecek sert fırçalar, temiz çelik bilyeler, tel fırçalar, aşındırıcılar (diş macunları gibi), organik çözücüler (alkol, aseton, muz yağı vb.), kaynar su, asit veya alkali maddeler kullanmayın. Kaynar su ve benzen gibi organik çözücüler plastik parçaları deforme edebilir veya zarar verebilir.
- Kısa devreleri önlemek veya daldırma sonrasında elektrik yalıtımını etkilememek için temizlik sırasında doğrudan su veya diğer sıvılarla durulamayın.



Buz çözme ve temizleme için lütfen buzdolabının fişini çekin.

4.2 Buz çözme

- Buzdolabını fişten çekin.
- Yiyecekleri buzdolabından çıkarın ve yiyeceklerin erimesini önlemek için uygun şekilde yerleştirin.
- Drenaj borusunu temizleyin (astarın zarar görmesini önlemek için yumuşak malzemeler kullanın), Buz çözme için su kaplarını hazırlayın. (kompresör bölmesi su boşaltma tepsisini temizlemeye dikkat edin, yere taşmasını önleyin).
- Doğal buz çözme için doğal sıcaklığı kullanabilir, donu ortadan kaldırmak için buz küreği de kullanabilirsiniz (astar veya boruya zarar vermemek için plastik veya ahşap buz küreği kullanmak için)
- Buz çözme işlemi hızlandırmak için uygun miktarda sıcak su da kullanabilirsiniz, buz çözme işleminden sonra suyu kurulamak için kuru bir havlu kullanabilirsiniz.
- Buz çözme işleminden sonra yiyecekleri dolaba geri koyun ve buzdolabını çalıştırın.

4.3 Faaliyet dışı

- Elektrik kesintisi: Elektrik kesintisi durumunda, yaz aylarında olsa bile, cihazın içindeki yiyecekler birkaç saat saklanabilir; elektrik kesintisi sırasında, kapı açma süreleri azaltılacak ve cihaza daha fazla taze yiyecek konulmayacaktır.
- Uzun süre kullanılmaması: Cihazın fişi çekilmeli ve ardından temizlenmelidir; daha sonra kokuyu önlemek için kapılar açık bırakılır.
- Taşınma: Buzdolabı taşınmadan önce, içindeki tüm nesnelere çıkarılmalı, cam bölmeler, sebzelik, dondurucu bölme çekmeceleri vb. bantla sabitlenmeli ve dengeleme ayakları sıkılmalıdır; kapılar kapatılmalı ve bantla kapatılmalıdır. Taşıma sırasında cihaz baş aşağı veya yatay olarak yatırılmamalı veya titreştirilmemelidir; hareket sırasında eğim 45°den fazla olmamalıdır.



Cihaz çalıştırdıktan sonra sürekli olarak çalışmalıdır. Genel olarak, cihazın çalışması kesintiye uğratılmamalıdır; aksi takdirde kullanın ömrü bozulabilir

Tablo 1 İklim sınıfları

| Sınıf | Sembol | Ortam Sıcaklık Aralığı, °C |
|----------------------|--------|----------------------------|
| Genişletilmiş Ilıman | SN | +10 ile +32 arası |
| Ilıman | N | +16 ile +32 arası |
| Subtropikal | ST | +16 ile +38 arası |
| Tropikal | T | +16 ile +43 arası |

Genişletilmiş ılıman: bu soğutma cihazı, +10°C ile +32°C arasında değişen ortam sıcaklıklarında kullanılmak üzere tasarlanmıştır.

Ilıman: bu soğutma cihazı, +16°C ile +32°C arasında değişen ortam sıcaklıklarında kullanılmak üzere tasarlanmıştır.

Subtropikal: bu soğutma cihazı, +16°C ile +38°C arasında değişen ortam sıcaklıklarında kullanılmak üzere tasarlanmıştır.

Tropikal: bu soğutma cihazı, +16°C ile +43°C arasında değişen ortam sıcaklıklarında kullanılmak üzere tasarlanmıştır.

5 Sorun giderme

5.1 Aşağıdaki basit sorunları kendi başınıza çözmeyi deneyebilirsiniz. Eğer çözemerseniz, lütfen satış sonrası departmanı ile iletişime geçin.

| | |
|-------------------------------------|---|
| Çalışmıyor | Cihazın elektriğe bağlı olup olmadığını veya fişin iyi temas edip etmediğini kontrol edin Voltajın çok düşük olup olmadığını kontrol edin Elektrik kesintisi olup olmadığını veya kısmi devrelerin atıp atmadığını kontrol edin |
| Koku | Kokulu gıdalar sıkıca sarılmalıdır Çürümüş gıda olup olmadığını kontrol edin Buzdolabının içini temizleyin |
| Kompresörün uzun süre çalışması | Ortam sıcaklığının yüksek olduğu yaz aylarında buzdolabının uzun süre çalışması normaldir Cihazın içinde aynı anda çok fazla yiyecek olması tavsiye edilmez Yiyecekler cihaza konulmadan önce soğumalıdır Kapılar çok sık açılıyor |
| Işık çalışmıyor | Buzdolabının güç kaynağına bağlı olup olmadığını ve aydınlatma ışığının hasarlı olup olmadığını kontrol edin Lambanın bir uzman tarafından değiştirilmesini sağlayın |
| Kapılar düzgün şekilde kapatılmıyor | Kapı yiyecek paketleri tarafından sıkıştırılmış Çok fazla yiyecek yerleştirilmiş Buzdolabı eğik |
| Yüksek ses | Zeminin düz olup olmadığını ve buzdolabının dengeli bir şekilde yerleştirilip yerleştirilmediğini kontrol edin Aksesuarların uygun yerlere yerleştirilip yerleştirilmediğini kontrol edin |
| Conta boşluğu | Kapı contası üzerindeki yabancı maddeleri çıkarın Kapı contasını ısıtın ve ardından restorasyon için soğutun (veya elektrikli bir kurutucu ile üfleyin veya ısıtmak için sıcak bir havlu kullanın) |
| Su kabı taşıyor | Haznede çok fazla yiyecek var veya depolanan yiyecekler çok fazla su içeriyor. Kapılar düzgün kapatılmamıştır, bu da hava girişi nedeniyle buzlanmaya ve buz çözme nedeniyle artan suya neden olur. |
| Yan yüzeyde aşırı ısı | Dahili kondansatörün gövde üzerinden ısı yayması, ki bu normaldir Yüksek ortam sıcaklığı, çok fazla yiyecek depolanması veya kompresörün kapatılması nedeniyle gövde ısındığında, ısı dağılımını kolaylaştırmak için sağlam bir havalandırma sağlayın. |
| Yüzey yoğuşması | Ortam nemi çok yüksek olduğunda buzdolabının dış yüzeyinde ve kapı contalarında yoğuşma olması normaldir. Yoğuşma suyunu temiz bir havluyla silmeniz yeterlidir. |
| Gürültü | Vızılıtı: Kompresör çalışma sırasında vızılıtı üretebilir ve vızılıtılar özellikle başlatma veya durdurma sırasında yüksektir. Bu normal bir durumdur. Gıcırtı: Cihazın içinde akan soğutucu akışkan gıcırtı üretebilir, bu normaldir. |

Üretici Firma:
Hefei Hualing Co., Ltd.
No.176 JinXiu Road, Hefei Economy & Technology
Development Area, 230601, Hefei, Anhui, P.R. China

simfer

OFFICE TYPE
SR-2513



INSTRICUTION MANUAL

Please read and save all instructions to ensure
safe and effective use of this Appliance

CONTENTS

| | |
|---|----|
| 1 Safety warnings | |
| 1.1 Warning | 35 |
| 1.2 Meanings of safety warning symbols | 37 |
| 1.3 Electricity related warnings | 37 |
| 1.4 Warnings for using | 38 |
| 1.5 Warnings for placement | 38 |
| 1.6 Warnings for energy | 39 |
| 1.7 Warnings for disposal | 39 |
| 2 Proper use of the refrigerator | |
| 2.1 Placement 2 | 40 |
| 2. Levelling feet | 41 |
| 2.3 Door Right-Left Change | 42 |
| 2.4 Changing the Light(optional) | 43 |
| 2.5 Starting to use | 44 |
| 2.6 Energy saving tips | 44 |
| 3 Structure and functions | |
| 3.1 Key components | 45 |
| 3.2 Functions | 46 |
| 4 Maintenance of refrigerator | |
| 4.1 Cleaning | 47 |
| 4.2 Defrost | 47 |
| 4.3 Stop using | 47 |
| 5 Trouble shooting | |
| 5.1 Trouble shooting | 48 |

1 Safety warnings

1.1 Warning



Warning: risk of fire / flammable materials

This appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail applications.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

The appliance has to be unplugged after use and before carrying out user maintenance on the appliance.

Warning: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

Warning: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

Warning: Do not damage the refrigerant circuit.

Warning: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

Warning: Please abandon the refrigerator according to local regulators for its use flammable blowing gas and refrigerant.

Warning: When positioning the appliance, ensure the supply cord is not trapped or damaged.

Warning: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

Do not use extension cords or ungrounded (two prong) adapters.

Danger: Risk of child entrapment. Before you throw away your old refrigerator or freezer:

–Take off the doors.

–Leave the shelves in place so that children may not easily climb inside.

The refrigerator must be disconnected from the source of electrical supply before attempting the installation of accessory.

Refrigerant and cyclopentane foaming material used for the appliance are flammable. Therefore, when the appliance is scrapped, it shall be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm.

The necessity that, for doors or lids fitted with locks and keys, the keys be kept out of the reach of children and not in the vicinity of the refrigerating appliance, in order to prevent children from being locked inside .

For EU standard: This appliance can be used by children aged from 8 years and above and persons with reduce physical sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.

To avoid contamination of food, please respect the following instructions:

- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- Clean regularly surfaces that can come in contact with food and accessible drainage systems.
- Clean water tanks if they have not been used for 48 h; flush the water system connected to a water supply if water has not been drawn for 5 days. (note 1)
- Store raw meat and fish in suitable containers in the refrigerator, so that it is not in contact with or drip onto other food.
- Two-star frozen-food compartments are suitable for storing pre-frozen food, storing or making ice-cream and making ice cubes. (note 2)
- One-, two- and three-star compartments are not suitable for the freezing of fresh food. (note 3)
- For appliances without a 4-star compartment: this refrigerating appliance is not suitable for freezing foodstuffs. (note 4)
- If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.

Note 1,2,3,4: Please confirm whether it is applicable according to your product compartment type.

For a freestanding appliance: this refrigerating appliance is not intended to be used as a built-in appliance.




Any replacement or maintenance of the LED lamps is intended to be made by the manufacturer, its service agent or similar qualified person. (See chapter 2.4 for lamp replacement)

Warning: To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.

Warning: Connect to potable water supply only. (Suitable for ice making machine)


To Prevent A Child From Being Entrapped, Keep Out Of Reach Of Children And Not In The Vicinity Of Freezer (Or Refrigerator). (Suitable for products with locks)

1.2 Meaning of safety warning symbols


| | |
|---|---|
|  | This is a prohibition symbol. Any in compliance with instructions marked with this symbol may result in damage to the product or endanger the personal safety of the user. |
|  | This is a warning symbol. It is required to operate in strict observance of instructions marked with this symbol; or otherwise damage to the product or personal injury may be caused. |
|  | This is a cautioning symbol. Instructions marked with this symbol require special caution. Insufficient caution may result in slight or moderate injury, or damage to the product. |

This manual contains lots of important safety information which shall be observed by the users.

1.3 Electricity related warnings




- Do not pull the power cord when pulling the power plug of the refrigerator. Please firmly grasp the plug and pull out it from the socket directly.
- To ensure safe use, do not damage the power cord or use the power cord when it is damaged or worn.



- Please use a dedicated power socket and the power socket shall not be shared with other electrical appliances. The power plug should be firmly contacted with the socket or else fires might be caused.
- Please ensure that the grounding electrode of the power socket is equipped with a reliable grounding line.




- Please turn off the valve of the leaking gas and then open the doors and windows in case of leakage of gas and other flammable gases. Do not unplug the refrigerator and other electrical appliances considering that spark may cause a fire.




- Do not use electrical appliances on the top of the appliance, unless they are of the type recommended by the manufacturer.

1.4 Warnings for using




- Do not arbitrarily disassemble or reconstruct the refrigerator, nor damage the refrigerant circuit; maintenance of the appliance must be conducted by a specialist
- Damaged power cord must be replaced by the manufacturer, its maintenance department or related professionals in order to avoid danger.



- The gaps between refrigerator doors and between doors and refrigerator body are small, be noted not to put your hand in these areas to prevent from squeezing the finger. Please be gentle when close the refrigerator door to avoid falling articles.
- Do not pick foods or containers with wet hands in the freezing chamber when the refrigerator is running, especially metal containers in order to avoid frostbite.




- Do not allow any child to get into or climb the refrigerator; otherwise suffocation or falling injury of the child may be caused.




- Do not place heavy objects on the top of the refrigerator considering that objectives may fall when close or open the door, and accidental injuries might be caused.
- Please pull out the plug in case of power failure or cleaning. Do not connect the refrigerator to power supply within five minutes to prevent damages to the compressor due to successive starts.


1.5 Warnings for placement



- Do not put flammable, explosive, volatile and highly corrosive items in the refrigerator to prevent damages to the product or fire accidents.
- Do not place flammable items near the refrigerator to avoid fires.



- The refrigerator is intended for household use, such as storage of foods; it shall not be used for other purposes, such as storage of blood, drugs or biological products, etc.



- Do not store beer, beverage or other fluid contained in bottles or enclosed containers in the freezing chamber of the refrigerator; otherwise the bottles or enclosed containers may crack due to freezing to cause damages.

1.6 Warnings for energy

- 1) Refrigerating appliances might not operate consistently (possibility of defrosting of contents or temperature becoming too warm in the frozen food compartment) when sited for an extended period of time below the cold end of the range of temperatures for which the refrigerating appliance is designed.
- 2) The fact that effervescent drinks should not be stored in food freezer compartments or cabinets or in low-temperature compartments or cabinets, and that some products such as water ices should not be consumed too cold;
- 3) The need to not exceed the storage time(s) recommended by the food manufacturers for any kind of food and particularly for commercially quick-frozen food in food-freezer and frozen-food storage compartments or cabinets;
- 4) The precautions necessary to prevent an undue rise in the temperature of the frozen food while defrosting the refrigerating appliance, such as wrapping the frozen food in several layers of newspaper.
- 5) The fact that a rise in temperature of the frozen food during manual defrosting, maintenance or cleaning could shorten the storage life.

1.7 Warnings for disposal

Refrigerant and cyclopentane foaming material used for the refrigerator are flammable. Therefore, when the refrigerator is scraped, it shall be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm.



When the refrigerator is scraped, disassemble the doors, and remove gasket of door and shelves; put the doors and shelves in a proper place, so as to prevent trapping of any child.




Correct Disposal of this product :


This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

2 Proper use of the refrigerator


2.1 Placement




- Before use, remove all packing materials, including bottom cushions, foam pads and tapes inside of the refrigerator; tear off the protective film on the doors and the refrigerator body.



- Keep away from heat and avoid direct sunlight. Do not place the freezer in moist or watery places to prevent rust or reduction of insulating effect.
- Do not spray or wash the refrigerator; do not put the refrigerator in moist places easy to be splashed with water so as not to affect the electrical insulation properties of the refrigerator.



- The refrigerator is placed in a well-ventilated indoor place; the ground shall be flat, and sturdy (rotate left or right to adjust the wheel for levelling if unstable).



- The top space of the refrigerator shall be greater than 30cm, and The refrigerator should be placed against a wall with a free distance more than 10cm to facilitate heat dissipation.


ⓘ Precautions before installation:

Information in the Instruction Manual is only for reference. The physical product may differ. Before installation and adjusting of accessories, it shall be ensured that the refrigerator is disconnected from power.

Precautions shall be taken to prevent fall of the handle from causing any personal injury.

2.2 Levelling feet

Schematic diagram of the levelling feet







(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

Adjusting procedures:


- a. Turn the feet clockwise to raise the refrigerator;
- b. Turn the feet counterclockwise to lower the refrigerator;
- c. Adjust the right and left feet based on the procedures above to a horizontal level.

2.3 Door Right-Left Change


| List of tools to be provided by the user | | | |
|---|----------------------|---|------------------------------------|
|  | Cross screwdriver |  | Putty knife thin-blade screwdriver |
|  | 5/16" socket spanner |  | Masking tape |

| Parts to be used for door reverse | | | |
|-----------------------------------|-----------------------|--------|---|
| Number | Name | Number | Note |
| 1 | Upper hinge | 1 | Pre-installed on the refrigerator, still used when door is reversed |
| 2 | Hinge cover | 1 | Pre-installed on the refrigerator, still used when door is reversed |
| 3 | Tapping locking screw | 5 | Pre-installed on the refrigerator, still used when door is reversed |
| 4 | Hole cap | 1 | Pre-installed on door end caps, still used when door is reversed |
| 5 | Pin | 2 | Pre-installed on the refrigerator, still used when door is reversed |
| 6 | Lower hinge assembly | 1 | Pre-installed on the refrigerator, still used when door is reversed |
| 7 | Levelling foot | 1 | Pre-installed on the refrigerator, still used when door is reversed |
| 8 | Stopper | 1 | Pre-installed on door end caps, still used when door is reversed |
| 9 | Tapping screw | 1 | Pre-installed on door end caps, still used when door is reversed |

- 1) Power off the refrigerator, and remove all objects from the door trays.
- 2) Dismantle the hinge cover, screws and upper hinge, and remove the hole cap and pins from the other side.




- 3) Remove the door first, then remove the lower hinge assembly and levelling foot, interchange the positions of the lower hinge assembly and levelling foot and install them.




(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

4) Dismantle the stopper under the door, then assemble the stopper on the other side.



5) Install the door on the lower hinge assembly, and then install the upper hinge, hinge cover, pins and hole cap in sequence.




(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

2.4 Changing the Light(optional)


Any replacement or maintenance of the LED lamps is intended to be made by the manufacturer, its service agent or similar qualified person. Replacement must first cut off the power supply.

(Above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

2.5 Starting to use



- Before initial start, keep the refrigerator still for half an hour before connecting it to power supply.
- Before putting any fresh or frozen foods, the refrigerator shall have run for 2-3 hours, or for above 4 hours in summer when the ambient temperature is high.




- Spare enough space for convenient opening of the doors and drawers or statement by the distributor.

2.6 Energy saving tips

- The appliance should be located in the coolest area of the room, away from heat producing appliances or heating ducts, and out of the direct sunlight.
- Let hot foods cool to room temperature before placing in the appliance. Overloading the appliance forces the compressor to run longer. Foods that freeze too slowly may lose quality, or spoil.
- Be sure to wrap foods properly, and wipe containers dry before placing them in the appliance. This cuts down on frost build-up inside the appliance.
- Appliance storage bin should not be lined with aluminum foil, wax paper, or paper toweling. Liners interfere with cold air circulation, making the appliance less efficient.
- Organize and label food to reduce door openings and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.

3 Structure and functions

3.1 Key components




⚠ (The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

Refrigerating chamber

- The Refrigerating Chamber is suitable for storage of a variety of fruits, vegetables, beverages and other food consume in the short term. Cooking foods shall not be put in the refrigerating chamber until cooled to room temperature. Suggested storage time 3days to 5days. It is the most energy efficient to place food in the position shown in the picture above.
- Foods are recommended to be sealed up before putting into the refrigerator.
- It is recommended to put bottled or canned drinks and other items on the door;

Note: Storage of too much food during operation after the initial connection to power may adversely affect the freezing effect of the refrigerator. Foods stored shall not block the air outlet; or otherwise the freezing effect will also be adversely affected.

3.2 Functions



⚠ (The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

- Turn the temperature control knob to MAX, the internal temperature of the refrigerator becomes lower.
- Turn the temperature control knob to MIN, the internal temperature of the refrigerator becomes higher.
- The letter on the knob only represents the level, but does not mean the specific temperature, the "OFF" means stop working.
- Recommended gear: "MED".
- If there is no special needs, please avoid setting the gear at MAX all the time so as to make sure you can prevent the tank bladder from frosting.

4 Maintenance of refrigerator

4.1 Cleaning

- Dusts behind the refrigerator and on the ground shall be timely cleaned to improve the cooling effect and energy saving.
- Check the door gasket regularly to make sure there are no debris. Clean the door gasket with a soft cloth dampened with soapy water or diluted detergent.
- The interior of the refrigerator should be cleaned regularly to avoid odor.
- Please turn off the power before cleaning interior, remove all foods, drinks, shelves, drawers, etc.
- Use a soft cloth or sponge to clean the inside of the refrigerator, with two tablespoons of baking soda and a quart of warm water. Then rinse with water and wipe clean. After cleaning, open the door and let it dry naturally before turning on the power.
- For areas that are difficult to clean in the refrigerator (such as narrow sandwiches, gaps or corners), it is recommended to wipe them regularly with a soft rag, softbrush, etc. and when necessary, combined with some auxiliary tools (such as thin sticks) to ensure no contaminants or bacterials accumulation in these areas.
- Do not use soap, detergent, scrub powder, spray cleaner, etc., as these may cause odors in the interior of the refrigerator or contaminated food.
- Clean the bottle frame, shelves and drawers with a soft cloth dampened with soapy water or diluted detergent. Dry with a soft cloth or dry naturally.
- Wipe the outer surface of the refrigerator with a soft cloth dampened with soapy water, detergent, etc., and then wipe dry.
- Do not use hard brushes, clean steel balls, wire brushes, abrasives (such as toothpastes), organic solvents (such as alcohol, acetone, banana oil, etc.), boiling water, acid or alkaline items, which may damage the cooler surface and interior. Boiling water and organic solvents such as benzene may deform or damage plastic parts.
- Do not rinse directly with water or other liquids during cleaning to avoid short circuits or affect electrical insulation after immersion.



⚠ Please unplug the refrigerator for defrost and cleaning.

4.2 Defrost

- Power off the refrigerator.
- Remove the food from the refrigerator and place it properly to prevent food from melting.
- Clear the drain pipe (to use soft materials to prevent damage to the liner), Prepare the water containers for defrosting.
(pay attention to clean the compressor compartment water draining tray, avoiding overflow to the ground).
- You can use the natural temperature for the natural defrost, you can also use the ice shovel to eliminate the frost (to use plastic or wooden ice shovel, for avoiding damage to the liner or pipe)
- You can also use the appropriate amount of hot water to speed up the defrost, with a dry towel to dry the water after defrosting.
- After defrosting, put back the foods in cabinet, and power on the refrigerator.

4.3 Stop using

- Power failure: In case of power failure, even if it is in summer, foods inside the appliance can be kept for several hours; during the power failure, the times of door opening shall be reduced, and no more fresh food shall be put into the appliance.
- Long-time nonuse: The appliance shall be unplugged and then cleaned; then the doors are left open to prevent odor.
- Moving: Before the refrigerator is moved, take all objects inside out, fix the glass partitions, vegetable holder, freezing chamber drawers and etc. with tape, and tighten the leveling feet; close the doors and seal them with tape. During moving, the appliance shall not be laid upside down or horizontally, or be vibrated; the inclination during movement shall be no more than 45°.

⚠ The appliance shall run continuously once it is started. Generally, the operation of the appliance shall not be interrupted; or otherwise the service life may be impaired

5. Trouble shooting

5.1 You may try to solve the following simple problems by yourself.

If them cannot be solved, please contact the after-sales department.

| | |
|---------------------------------------|--|
| Not work | <p>Check whether the appliance is connected to power or whether the plug is in well contact</p> <p>Check whether the voltage is too low</p> <p>Check whether there is a power failure or partial circuits have tripped</p> |
| Odor | <p>Odorous foods shall be tightly wrapped</p> <p>Check whether there is any rotten food</p> <p>Clean the inside of the refrigerator</p> |
| Long-time operation of the compressor | <p>Long operation of the refrigerator is normal in summer when the ambient temperature is high</p> <p>It is not suggestible having too much food in the appliance at the same time</p> <p>Food shall get cool before being put into the appliance</p> <p>The doors are opened too frequently</p> |
| Light not work | <p>Check whether the refrigerator is connected to power supply and whether the illuminating light is damaged</p> <p>Have the light replaced by a specialist</p> |
| Doors cannot be properly closed | <p>The door is stuck by food packages Too much food is placed</p> <p>The refrigerator is tilted</p> |
| Loud noise | <p>Check whether the floor is level and whether the refrigerator is placed stably</p> <p>Check whether accessories are placed at proper locations</p> |
| Gasket gap | <p>Remove foreign matters on the door seal</p> <p>Heat the door seal and then cool it for restoration (or blow it with an electrical drier or use a hot towel for heating)</p> |
| Water tray overflows | <p>There is too much food in the chamber or food stored contains too much water, resulting in heavy defrosting</p> <p>The doors are not closed properly, resulting in frosting due to entry of air and increased water due to defrosting</p> |
| Over heat on sidewall | <p>Heat dissipation of the built-in condenser via the housing, which is normal</p> <p>When housing becomes hot due to high ambient temperature, storage of too much food or shutdown of the compressor is shut down, provide sound ventilation to facilitate heat dissipation</p> |
| Surface condensation | <p>Condensation on the exterior surface and door seals of the refrigerator is normal when the ambient humidity is too high. Just wipe the condensate with a clean towel.</p> |
| Noise | <p>Buzz: The compressor may produce buzzes during operation, and the buzzes are loud particularly upon start or stop. This is normal.</p> <p>Creak: Refrigerant flowing inside of the appliance may produce creak, which is normal.</p> |

Table 1 Climate classes

| Class | Symbol | Ambient temperature range °C |
|---------------------------|---------------|-------------------------------------|
| Extended temperate | SN | + 10 to + 32 |
| Temperate | N | + 16 to + 32 |
| Subtropical | ST | + 16 to + 38 |
| Tropical | T | + 16 to + 43 |

Extended temperate: 'this refrigerating appliance is intended to be used at ambient temperatures ranging from 10 °C to 32 °C';

temperate: 'this refrigerating appliance is intended to be used at ambient temperatures ranging from 16 °C to 32 °C';

Subtropical: 'this refrigerating appliance is intended to be used at ambient temperatures ranging from 16 °C to 38 °C';

Tropical: 'this refrigerating appliance is intended to be used at ambient temperatures ranging from 16 °C to 43 °C';

If the wine cooler operates outside the climate class(ambient temperature range)for which it is rated then it may not be able to maintain satisfactory internal temperatures.

Special for new European standard

- The ordered parts in the following table can be acquired from channel _:

| Ordered Part | Provided by | Minimum Time Required for Provision |
|------------------------|--|--|
| thermostats | Professional maintenance personnel | At least 7 years after the last model is launched on the market |
| temperature sensors | Professional maintenance personnel | At least 7 years after the last model is launched on the market |
| printed circuit boards | Professional maintenance personnel | At least 7 years after the last model is launched on the market |
| light sources | Professional maintenance personnel | At least 7 years after the last model is launched on the market |
| door handles | Professional repairers and final users | At least 7 years after the last model is launched on the market |
| door hinges | Professional repairers and final users | At least 7 years after the last model is launched on the market |
| trays | Professional repairers and final users | At least 7 years after the last model is launched on the market |
| baskets | Professional repairers and final users | At least 7 years after the last model is launched on the market |
| door gaskets | Professional repairers and final users | At least 10 years after the last model is launched on the market |

- The shortest period for providing after-sales spare parts is 15 working days.
- The model information and model identification in the product database can be obtained by scanning the web link on the QR code (if any) on the product energy efficiency label.