


Buzdolabı Kullanma Kılavuz



ÇİFT KAPILI
SR-2515

TR-ENG

simfer

İÇİNDEKİLER

GÜVENLİK UYARILARI-----	03
ÜRÜNE YÖNELİK GENEL BİLGİLER -----	05
ÜRÜNÜN KURULUMU-----	06
KULLANIM TALİMATI -----	12
TEMİZLİK VE BAKIM-----	15
SORUN GİDERME -----	17

1 Güvenlik Uyarıları

1.1 Uyarı



Uyarı: yangın riski / yanıcı maddeler

Bu cihaz, mağazalardaki, ofislerdeki ve diğer çalışma ortamlarındaki personel mutfak alanları; çiftlik evleri ve otellerdeki, motellerdeki ve diğer konut tipi ortamlardaki müşteriler tarafından; yatak ve kahvaltı tipi ortamlar; catering ve benzeri perakende olmayan uygulamalar gibi ev ve benzeri uygulamalarda kullanılmak üzere tasarlanmıştır.

Bu cihaz, güvenliklerinden sorumlu bir kişi tarafından gözetim altında tutulmadıkları veya cihazın kullanımıyla ilgili talimat verilmediği sürece, fiziksel, duyuşsal veya zihinsel yetenekleri sınırlı olan veya deneyim ve bilgi eksikliği olan kişiler (çocuklar dahil) tarafından kullanılmak üzere tasarlanmamıştır).

Çocuklar, cihazla oynamadıklarından emin olmak için gözetim altında tutulmalıdır.

Eğer besleme kablosu hasar görürse, bir tehlikeyi önlemek için üretici, servis temsilcisi veya benzer kalifiye kişiler tarafından değiştirilmelidir.

Yanıcı itici gaz içeren aerosol kutuları gibi patlayıcı maddeleri bu cihazda saklamayın.

Kullanımdan sonra ve cihaz üzerinde kullanıcı bakımı yapmadan önce cihazın fişi çekilmelidir.

Uyarı: Cihaz muhafazasındaki veya ankastre yapıdaki havalandırma açıklıklarını engellerden uzak tutun.

Uyarı: Buz çözme işlemini hızlandırmak için üretici tarafından tavsiye edilenler dışında mekanik cihazlar veya başka araçlar kullanmayın.

Uyarı: Soğutucu gaz devresine zarar vermeyin.

Uyarı: Üretici tarafından tavsiye edilen tipte olmadıkça, cihazın gıda saklama bölmelerinin içinde elektrikli aletler kullanmayın.

Uyarı: Yanıcı üfleme gazı ve soğutucu gaz kullanması nedeniyle lütfen buzdolabını yerel regülatörlere uygun olarak bırakınız.

Uyarı: Cihazı yerleştirirken, besleme kablosunun sıkışmadığından veya hasar görmediğinden emin olun.

Uyarı: Cihazın arkasına birden fazla taşınabilir priz veya taşınabilir güç kaynağı yerleştirmeyin.

Uzatma kabloları veya topraklanmamış (iki uçlu) adaptörler kullanmayın.

Tehlike: Çocuk sıkışması riski. Eski buzdolabınızı veya dondurucunuzu atmadan önce:

- Kapıları çıkarın.

-Çocukların kolayca içeri tırmanmaması için rafları yerinde bırakın.

Aksesuar takmaya başlamadan önce buzdolabının elektrik kaynağı ile bağlantısı kesilmelidir.

Cihaz için kullanılan soğutucu akışkan ve siklopentan köpük malzemesi yanıcıdır. Bu nedenle, cihaz hurdaya çıkarıldığında, herhangi bir ateş kaynağından uzak tutulmalı ve çevreye zarar vermesini veya başka herhangi bir zararı önlemek için yanma yoluyla imha edilmesinin dışında ilgili niteliklere sahip özel bir geri kazanım şirketi tarafından geri kazanılmalıdır.

Kilit ve anahtarlarla donatılmış kapı veya kapaklarda, çocukların içeride kilitli kalmasını önlemek için anahtarların çocukların erişemeyeceği bir yerde ve soğutucu cihazın yakınında bulundurulması gerekliliği.

EN standardı için: Bu cihaz, 8 yaş ve üzeri çocuklar ve fiziksel duyuşsal veya zihinsel yetenekleri azalmış veya deneyim ve bilgi eksikliği olan kişiler tarafından, cihazın güvenli bir şekilde kullanılmasına ilişkin gözetim veya talimat verildiği ve ilgili tehlikeleri anladıkları takdirde kullanılabilir. Çocuklar cihaz ile oynamamalıdır. Temizlik ve kullanıcı bakımı gözetim olmadan çocuklar tarafından yapılmamalıdır. 3 ila 8 yaş arası çocukların soğutucu cihazları yüklemelerine ve boşaltmalarına izin verilir.

Gıdaların kontaminasyonunu önlemek için lütfen aşağıdaki talimatlara uyun:

- Kapağın uzun süre açılması, cihazın bölmelerindeki sıcaklığın önemli ölçüde artmasına neden olabilir.
- Gıda ile temas edebilecek yüzeyleri ve erişilebilir drenaj sistemlerini düzenli olarak temizleyin.
- Su tanklarını 48 saat boyunca kullanılmamışlarsa temizleyin; 5 gün boyunca su çekilmemişse bir su kaynağına bağlı su sistemini yıkayın. (not 1)
- Çiğ et ve balığı, diğer yiyeceklerle temas etmeyecek veya üzerine damlamayacak şekilde buzdolabında uygun kaplarda saklayın.
- İki yıldızlı dondurulmuş gıda bölmeleri önceden dondurulmuş gıdaları saklamak, dondurma saklamak veya yapmak ve buz küpleri yapmak için uygundur. (not 2)
- Bir, iki ve üç yıldızlı bölmeler taze gıdaların dondurulması için uygun değildir (not 3)
- 4 yıldızlı bölümü olmayan cihazlar için: Bu soğutucu cihaz gıda maddelerinin dondurulması için uygun değildir. (not 4)
- Soğutucu cihaz uzun süre boş bırakılırsa, cihaz içinde küf oluşumunu önlemek için kapatın, buzunu çözün, temizleyin, kurulaşın ve kapıyı açık bırakın.

Not 1,2,3,4: Lütfen ürün bölümü tipinize göre geçerli olup olmadığını onaylayın.

Bağımsız bir cihaz için: Bu soğutucu cihaz ankastre bir cihaz olarak kullanılmak üzere tasarlanmamıştır.

LED lambaların değiştirilmesi veya bakımının üretici, servis temsilcisi veya benzeri kalifiye bir kişi tarafından yapılması amaçlanmıştır. (Lamba değişimi için bölüm 2.4'e bakın)

UYARI: Cihazın dengesizliğinden kaynaklanan bir tehlikeyi önlemek için, talimatlara uygun olarak sabitlenmelidir.

UYARI: Sadece içilebilir su kaynağına bağlayın. (Buz yapma makinesi için uygundur)

Bir Çocuğun Sıkışmasını Önlemek İçin, Çocukların Ulaşamayacağı Yerde Tutun ve Dondurucunun (Veya Buzdolabının) Çevresinde Bulundurmayın." (Kilitli ürünler için uygundur)




UYARI: Yangın Riski/ Yanıcı Malzeme

Cihaz için kullanılan soğutucu akışkan ve siklopentan köpük malzemesi yanıcıdır. Bu nedenle cihaz hurdaya çıkarıldığında, herhangi bir ateş kaynağından uzak tutulmalı ve çevreye Zarar vermesini veya başka herhangi bir zararı önlemek için yanma yoluyla imha edilmesinin dışında ilgili niteliklere sahip özel bir geri kazanım şirketi tarafından geri kazanılmalıdır.

ÜRÜNE YÖNELİK GENEL BİLGİLER

Bileşenlerin adları



- | | | | |
|---|-----------------------|---|-----------------|
| 1 | Buzluk Bölmesi Rafı | 4 | Küçük Kapı Rafı |
| 2 | Soğutucu Bölmesi Rafı | 5 | Büyük Kapı Rafı |
| 3 | Sebzelik kutusu | | |

DİKKAT

Yukarıdaki resim yalnızca referans amaçlıdır. Gerçek konfigürasyon ürünün fiziksel yapısına ya da distribütörün beyanına bağlı olacaktır.

ÜRÜNÜN KURULUMU

Kurulum Talimatı


İklim sınıflı soğutucu cihazlar için

- İklim sınıfına bağlı olarak, Bu soğutucu cihaz aşağıdaki tabloda belirtilen ortam sıcaklıkları aralığında kullanılmak üzere tasarlanmıştır.
- Ürün, belirtilen sıcaklık aralığının dışında kalan sıcaklıklarda düzgün çalışmayabilir.
- İklim sınıfı ürün etiketinde belirtilmiştir.

Sınıf	Simge	Ortam sıcaklığı aralığı °C	
		IEC 62552 (ISO 15502)	ISO 8561
Genişletilmiş sıcaklık	SN	+ 10 ila + 32	+ 10 ila + 32
İlman	N	+ 16 ila + 32	+ 16 ila + 32
Subtropikal	ST	+ 16 ila + 38	+ 18 ila + 38
Tropikal	T	+ 16 ila + 43	+ 18 ila + 43

Boyutlar ve Mesafeler


- Bitişikteki eşyalarla arada bırakılan mesafenin çok az olması halinde dondurma performansında azalma ve elektrik tüketiminde artış söz konusu olabilir. Buzdolabının her iki tarafıyla duvar arasında en az 100 mm boş alan bırakılmalı ve buzdolabının arka kısmıyla duvar arasındaki mesafe 75 mm'den fazla olmamalıdır.



DİKKAT

Yukarıdaki resim yalnızca referans amaçlıdır. Gerçek konfigürasyon ürünün fiziksel yapısına ya da distribütörün beyanına bağlı olacaktır.

Alan gereksinimi şeması (kapı açıkken ve kapı kapalıyken)



Genişlik	Toplam Yükseklik	Derinlik	Bölme Derinliği	135° kapı açılma genişliği	135° kapı açılma derinliği
A	B	C	C1	D	E
595	1760	550	470	991	975

Uyarı: Tüm boyutlar (mm) olarak belirtilmiştir

Sağ-sol kapı menteşe değişimi

Kullanıcı tarafından sağlanacak aletlerin listesi

	Alyan anahtarı-Yıldız tornavida
	Macun ispatulası Düz tornavida
	5/16'' lokma anahtarı
	Maskeleme bandı


Kapı açılma yönünü değiştirmek için kullanılacak parçalar

SN	Parçalar	Miktar
1	Sağ üst menteşe	1
2	Sağ üst menteşe kapağı	1
3	Üst menteşe mil yüzüğü	1
4	Üst menteşe vidası	3
5	Delik kapağı	1
6	Orta menteşe vidası	2
7	Orta menteşe	1
8	Delik tıpası	2
9	Orta direk vidası	1
10	Orta direk vida kapağı	1
11	Ayarlanabilir ayak	1
12	Alt menteşe vidası	3
13	Alt menteşe aksamı	1
14	Buzluk kapısı alt uç kapak vidası	1
15	Buzluk kapısı alt uç kapak sınırlama bloğu	1
16	Soğutucu kapısı alt uç kapak vidası	1
17	Soğutucu kapısı alt uç kapak sınırlama bloğu	1
18	Soğutucu kapısı üst uç kapak mil yüzüğü	1
19	Soğutucu kapısı alt desteği	1
20	Aksesuar paketi	4
21	Sağ kapı kendinden kilitleme	1


Notlar :

- 1-19/kapı değiştirilirken kullanılmak üzere buzdolabına önceden monte edilmiştir
- 20/Sol üst menteşe, sol üst menteşe kapağı, Sol kapı kendinden kilitleme, sol dekoratif kapak
- 21/Buzdolabına önceden takılmıştır, kapı yön değişimi sırasında sökülür ve muhafaza edilir


1. Bu işlemi uygulamadan önce lütfen cihazın güç bağlantısını kesiniz.
2. Üst menteşe kapağını, üst menteşeyi ve diğer tarafın delik kapağını söküp ardından buzlukun kapağını çıkarınız.




1. Orta menteşeyi ve vida deliği kapaklarını çıkarıp ve soğutucu kapısını sökünüz.




2. Alt menteşeyi, delik kapaklarını ve vidaları çıkarınız. Alt menteşe milini takınız ve ayağı alt menteşenin diğer tarafına doğru ayarlayıp menteşeyi karşı tarafa monte ediniz.




1. Vidayı, yüzük çubuğunu ve durdurucuyu soğutucu kapısından ve buzluk kapısından çıkardığınızda soğutucu kapısının alt kapağındaki destek de çıkmış olur.
2. Daha sonra bu parçaları aynı sırayla kapıların diğer tarafına monte ediniz.
3. Soğutucu kapısının üst kapağındaki yüzük çubuğunu borusunun ve delik kapağının pozisyonunu diğer tarafa geçirip buzluk kapısındaki üst menteşe yüzüğünü eksen yüzüğünün diğer tarafındaki deliğe monte ediniz.



4. Buzluk kapısını alt menteşeye oturtunuz ve orta menteşeyi, kapağı, vidayı ve vida kapağını monte ediniz.



5. Soğutucu kapısını alt menteşe üzerine oturtunuz ve üst menteşeyi, menteşe kapağını ve delik kapağını monte ediniz.





Dengeleme ayakları

Titreşimin önlenmesi için cihazın dengelenmesi gerekir.

Gerekirse dengeleme ayaklarını ayarlayarak zemindeki bozukluğu saf dışı bırakınız.

Kapının kapanmasını kolaylaştırmak için ön taraf arka taraftan biraz daha yüksek olmalıdır. Dolabı hafifçe yatırarak dengeleme ayaklarını kolayca döndürebilirsiniz.

Cihazı yükseltmek için dengeleme ayaklarını saat yönünün tersine  , alçaltmak içinse saat yönünde  çeviriniz.

Cihaza güç verilmesi


Ürünün kurulumunu yaptıktan sonra gücü açmadan önce lütfen en az 2 saat bekleyiniz, aksi takdirde soğutma kapasitesinde azalma ya da ürünün hasar görmesi söz konusu olabilir.

Enerji tasarrufuna ilişkin ipuçları

- Cihazı ocakların, radyatörlerin ya da diğer ısı kaynaklarının yakınına yerleştirmeyiniz. Ortam sıcaklığı yüksekse, kompresör daha sık ve daha uzun süreler boyunca çalışarak enerji tüketiminin artmasına neden olacaktır.
- Cihazın tabanında, yanlarında ve arkasında yeterli havalandırma sağlandığından emin olunuz.
- Lütfen "Kurulum" bölümündeki mesafe ölçülerini de dikkate alınız.
- Enerjinin en verimli şekilde kullanılmasını sağlamak için çekmeceleri ve rafları ürün genel görünümünde gösterildiği şekilde düzenleyiniz ve bu öneriye mümkün olduğu ölçüde bağlı kalınız.
- Daha geniş bir depolama alanı elde etmek için (örneğin büyük boyutlu soğutulmuş/dondurulmuş ürünler için) orta çekmeceleri ve rafları sökebilirsiniz. İhtiyaç duyulması halinde en üstteki ve en alttaki çekmeceler ve raflar çıkarılabilir.
- Soğutucu/buzluk bölmesi eşit şekilde doldurulduğu takdirde enerji tüketiminin ideal düzeyde olması sağlanır.
- Sıcak yiyecekleri soğutucu/buzluk bölmelerine yerleştirmeden önce soğumasını bekleyiniz. Buzdolabının içine konulan yiyeceklerin ısısının düşük olması enerji verimliliğini artırır.
- Dondurulmuş yiyecekleri soğutma bölümünde tutarak çözünüz. Dondurulmuş yiyeceklerin soğukluğu, soğutma bölümündeki enerji tüketimini azaltıp enerji verimliliğini artırır.
- Soğuk kaybını en aza indirmek için kapıyı ancak gerektiği kadar kısa süreler boyunca açık tutunuz. Kapının açık kalma süresinin kısa tutulması ve düzgün bir şekilde kapatılması enerji tüketimini azaltır.
- Sıcaklık değerinin gerekenden daha soğuk olmayacak şekilde ayarlanması enerji tüketiminin ideal seviyede tutulmasına katkı sağlar.
- Kapıların düzgün kapanmasını sağlamak ve enerji tüketiminin gereksiz yere artmasını önlemek için cihazınızın kapı contaları kusursuz durumda olmalıdır.

KULLANIM TALİMATI

Kontrol Düğmesi



- Sıcaklık kontrol düğmesini MAX konumuna getirdiğinizde buzdolabının iç sıcaklığı azalır.
- Sıcaklık kontrol düğmesini MIN konumuna getirdiğinizde buzdolabının iç sıcaklığı artar.
- Lütfen sıcaklığı "MAX" ve "MIN" konumları arasında ayarlayınız.
- Düğme "DEFROST" konumuna getirildiğinde, kompresör çalışmayı durdurur.

Yiyeceklerin saklanmasına ilişkin ipuçları

Buzluk bölümü





- Buzluk bölümü gıdaların düşük sıcaklık değerlerinde dondurulması, dondurulmuş gıdaların uzun süreli saklanması ve buz hazırlamak için tasarlanmıştır.
- Buzluktaki yıldız sınıflandırmalarını (4 yıldız, 2 yıldız ve 1 yıldız) ve dondurulmuş gıdalara uygun olan saklama sürelerini göz önünde bulundurunuz.
- Taze ve donmuş yiyecekleri yan yana koymayınız. Bu durum dondurulmuş yiyeceklerin erimesine neden olabilir.
- Büyük miktarlarda taze gıdayı (et, balık ya da kıyma gibi) dondururken, hızlı bir şekilde dondurulabilmeleri ve kolayca kullanılabilmesi için lütfen buzluga koymadan önce birkaç küçük parçaya bölünüz.
- Gıda üreticilerinin ambalajlar üzerinde belirttiği saklama sürelerine riayet ediniz, ambalaj üzerinde herhangi bir bilgi yer almıyorsa gıdalar satın alındıkları tarihten itibaren üç ayı aşan süreler boyunca dondurularak saklanmamalıdır.
- Dondurulmuş gıda alışverişi yaparken ürünün uygun sıcaklıkta dondurulduğundan ve ambalajın sağlam olduğundan emin olunuz.
- Dondurulmuş gıdalar yanlarındaki diğer gıdalara bulaşma olmaması için ayrı ve uygun paketler içinde tutulmalıdır. Buzu çözülmüş gıdaları zaman kaybetmeden tüketiniz ve kesinlikle yeniden dondurmayınız.
- Uzun süreli elektrik kesintisi yaşanması ya da cihazın arızalanması durumunda buzdolabının içindeki dondurulmuş gıdaları çıkarıp hala yenilebilir olup olmadıklarını kontrol ediniz ve yeterince serin bir yerde saklayınız ya da başka bir buzdolabına koyunuz.
- Yiyeceklerin buzunu çözmek için, buzluktan çıkarıp oda sıcaklığında ya da soğutucu bölümünde çözümesini bekleyiniz. Dondurulmuş yiyecekleri hızlı bir şekilde çözmek için mikrodalga fırınınızın buz çözme işlevini kullanabilirsiniz.
- Bir paket içindeki ürünün yalnızca bir kısmını çözmek istiyorsanız, ihtiyacınız olan kısmı çıkarıp geri kalanın ürünün içinde bulunduğu paketin ağzını hemen kapatınız. Bu sayede "buzluk yanığı" meydana gelmesini önleyerek ve paket içindeki kalan ürünün karlanma ihtimalini azaltabilirsiniz.

Soğutma bölümü

- Nemi ve buzlanmayı azaltmak için buzdolabı bölümüne ağzı kapalı olmayan kaplara konulmuş sıvılar bırakmayınız. Evaporatörün en soğuk kısımlarında buzlanma ihtimali söz konusu olur. Sıvıların kapağı açık şekilde saklanması daha sık buz çözme işlemi yapılmasını gerektirir.
- Soğutucu bölümüne kesinlikle sıcak yiyecekler koymayınız. Bunlar oda sıcaklığına ulaşacak şekilde soğutulduktan sonra yeterli hava sirkülasyonu sağlanacak şekilde soğutucu bölümüne yerleştirilmelidir.
- Duvara yapışarak donmalarına neden olmamak için yiyecekleri ya da yiyecek kaplarını buzdolabının arka duvarına yaslamayınız. Buzdolabının kapısını çok sık açıp kapatmayınız.
- Buzdolabına konulmuş et ve temizlenmiş balık (bir paket ya da plastik film içine konulmuş) gibi ürünler 1-2 gün içinde tüketilmelidir.
- Ambalaj içinde olmayan meyve ve sebzeler, taze meyve ve sebzeler için ayrılmış bölüme konulabilir

DİKKAT

Her bir bölmenin ideal sıcaklık ayarı ortam sıcaklığına bağlı olarak farklılık gösterir. Yukarıda belirtilen ideal sıcaklık değerleri 25 °C ortam sıcaklığını esas alır.

Sıra No.	Bölme TÜRÜ	Hedeflenen saklama soğukluğu [°C]	Uygun gıda
1	Soğutucu	$+2 \leq x \leq +8$	Yumurta, pişmiş gıdalar, ambalajlı yiyecekler, meyve ve sebzeler, süt ürünleri, kekler, içecekler ve diğer yiyecekler dondurma işlemine uygun değildir.
2	 Dört yıldız dereceli dondurma	$x \leq -18$	Dondurma özelliği hızlı dondurma işlemi gerçekleştirerek gıdaların hızlı bir şekilde dondurularak saklanmasını sağlar. Deniz ürünleri gibi dondurulmuş taze gıdalar için uygundur (balık, karides, kabuklu deniz ürünleri), tatlı su ürünleri ve et ürünleri. Saklama süresinin 3 ~ 6 ayla sınırlandırılması önerilmektedir ve saklama süresi uzadıkça tat ve besin değerlerinde azalma meydana gelir.
3	 Üç yıldız dereceli dondurma	$x \leq -18$	Dondurma özelliğine sahiptir. Deniz ürünleri gibi dondurulmuş taze gıdalar için uygundur (balık, karides, kabuklu deniz ürünleri), tatlı su ürünleri ve et ürünleri. 3 aydan daha uzun süreler boyunca tutulması tavsiye edilmez.
4	 İki yıldız dereceli dondurma	$x \leq -12$	Yalnızca dondurma gibi dondurulmuş olarak satılan gıdaların uzun olmayan süreler boyunca saklanması için uygundur. 1 aydan daha uzun süreler boyunca tutulması tavsiye edilmez.
5	 Bir yıldız dereceli dondurma	$x \leq -6$	Yalnızca soğutma ve dondurulmuş olarak satılan az miktarlardaki gıdaların kısa süreler boyunca saklanmasına uygundur. 1 haftadan daha uzun süreler boyunca tutulması tavsiye edilmez.
6	0-yıldız	$-6 \leq x \leq 0$	Taze kuzu, dana, balık, tavuk, bazı işlenmiş ambalajlı gıdalar, vb. (Aynı gün içinde, tercihen en fazla 3 gün içinde tüketilmesi önerilir). Kısmen sarılmış işlenmiş gıdalar (dondurulmaması gereken gıdalar).
7	Soğutma	$-2 \leq x \leq +3$	Taze/dondurulmuş kuzu eti, ana eti, tavuk, tatlı su ürünleri, vb. (0°C'nin altında 7 gün ve 0°C'nin üzerinde o gün içinde tüketilmesi önerilir, tercihen en fazla 2 gün). Deniz ürünlerinin 15 gün boyunca 0°C'nin altında, 0°C'nin üzerinde saklanması tavsiye edilmez.
8	Taze gıda	$0 \leq x \leq +4$	Taze kuzu, dana, balık, tavuk, pişmiş gıdalar, vb. (Aynı gün içinde, tercihen en fazla 3 gün içinde tüketilmesi önerilir).

● DİKKAT

Lütfen ambalaj üzerinde yer alan üretici talimatına dikkat ediniz. Lütfen farklı türdeki gıdaları satın aldığınız reyonlardaki hedef saklama soğukluğuna göre saklayınız.


TEMİZLİK VE BAKIM

Buz çözme

- Buzdolabını kapatınız. Buzdolabındaki yiyecekleri çıkarınız ve yiyeceklerin erimesini önlemek için uygun şekilde yerleştiriniz.
- Tahliye borusunu temizleyiniz (iç kaplamaya zarar vermemek için yumuşak malzemeler kullanınız), Buz çözme işleminde oluşacak suyu tutmak için kaplar hazırlayınız. (kompresör bölmesi su tahliye tepsisini mutlaka temizleyiniz, suyun taşarak yere dökülmesine engel olunuz).
- Buz çözme işlemini hızlandırmak için uygun miktarda sıcak su da kullanabilirsiniz, buz çözme işleminden sonra ıslaklığı kuru bir havlu yardımıyla giderebilirsiniz.
- Buz çözme işlemini hızlandırmak için uygun miktarda sıcak su da kullanabilirsiniz, buz çözme işleminden sonra ıslaklığı kuru bir havlu yardımıyla giderebilirsiniz.
- Buz çözme işleminden sonra yiyecekleri dolaba geri kaldırıp ve buzdolabına güç veriniz.


Kapı rafının temizlenmesi

- Rafi her iki elinizle tutarak şekilde gösterilen ok işaretinin yönüne göre yukarı doğru itip yerinden çıkarabilirsiniz.
- Kapı rafını temizledikten sonra rafı kapıdaki yuvasına hizalayıp ve yerine oturana kadar aşağı doğru itiniz. Ürünün bazı modellerinde montaj yüksekliği ayarlanabilmektedir.




Cam rafın temizlenmesi

- Buzdolabının iç kaplamasının raflara dayanan en iç kısmında bir destek yer aldığı için rafı çıkarmak için önce arka tarafını hafifçe yukarı kaldırıp daha sonra dışarı doğru çekmeniz gerekmektedir.
- Cam rafı temizledikten sonra rafı yatay olarak rayların üzerine yerleştiriniz ve arkalık yuvasına oturana kadar içeri doğru itiniz. Ürünün bazı modellerinde montaj yüksekliği ayarlanabilmektedir.



Çekmecenin temizlenmesi

- Çekmecenin içindeki ürünleri dışarı çıkarınız. Çekmecenin tutacağından tutarak son noktaya ulaşana kadar dışarı doğru çekiniz.
- Çekmeceyi yukarı kaldırıp dışarı çıkarınız.



Aşağıdaki durumlarda cihazı kullanmayınız

Elektrik kesintisi:

Elektrik kesintisi söz konusu olduğunda cihazın içindeki yiyeceklerin soğukluğu yaz aylarında dahi birkaç saat boyunca korunabilir; elektrik kesintisi sırasında, kapı açma süreleri son derece kısa tutulmalı ve cihaza başka taze gıdalar konulmamalıdır.

Uzun süre boyunca kullanım dışı bırakma:

Cihazın fişi çekilip temizlik işlemi yapılmalıdır; koku oluşumunu önlemek için kapılar açık bırakılmalıdır.

Taşıma:

Buzdolabını taşımadan önce, içindeki tüm ürünlerin çıkarılması; cam bölmelerin, sebzelik, buzluk bölme çekmecelerinin vb. bantla sabitlenmesi ve denge ayaklarının sonuna kadar sıkılarak kapıların kapatılması ve bantla sabitlenmesi gerekir. Taşıma sırasında cihaz baş aşağı ya da yatık tutulmamalı ya da titreşime maruz bırakılmamalıdır; taşıma sırasında cihaz 45°'den daha fazla yatırılmamalıdır.



Cihaz bir kez çalıştırdıktan sonra sürekli olarak çalışmaya devam etmelidir. Kullanım ömrü erken dolabileceği için genel olarak cihazın çalışması kesintiye uğratılmamalıdır. Elektrik kesintisi durumunda yiyeceklerin soğukluğu yaz aylarında dahi birkaç saat boyunca korunabilir; kapının açılma sıklığının azaltılması önerilir.

SORUN GİDERME

Aşağıdaki belirtilen basit sorunlar kullanıcı tarafından giderilebilir. Çözüm bulamadığınız sorunlar için lütfen satış sonrası servis departmanını arayınız.

Sorun	Olası neden
Cihaz çalışmıyor.	• Cihazın elektriğe bağlı olup olmadığını ya da fişinin tam olarak takılı olup olmadığını kontrol ediniz.
	• Voltajın çok düşük olup olmadığını kontrol ediniz.
	• Elektrik kesintisi olup olmadığını ya da sigortanın atıp atmadığını kontrol ediniz.
Koku.	• Kokulu gıdalar sıkıca sarılmalıdır.
	• Bozulmuş ürün bulunup bulunmadığını kontrol ediniz.
	• Buzdolabının içini temizleyiniz.
Kompresör çok uzun süre çalışıyor.	• Yaz aylarında ortam sıcaklığı yüksek olduğunda buzdolabı kompresörünün uzun süre çalışması normal bir durumdur.
	• Cihaz içinde çok fazla yiyecek bulundurulması tavsiye edilmemektedir.
	• Yiyecekler cihaza konulmadan önce soğumaları beklenmelidir.
	• Kapılar çok sık açılıp kapatılmaktadır.
Işık yanmıyor.	• Buzdolabının güç kaynağına bağlı olup olmadığını ve aydınlatma lambasının arızalı olup olmadığını kontrol ediniz.
	• Lambanın bir uzman tarafından değiştirilmesini sağlayınız.
Kapı düzgün kapanmıyor.	• Kapının arasında ürün ambalajı kalmış. Buzdolabına çok fazla yiyecek konulmuş.
	• Buzdolabı eğik pozisyonudadır.
Gürültülü çalışma.	• Zeminin düz ve buzdolabının dengeli bir şekilde yerleştirilmiş olup olmadığını kontrol ediniz.
	• Aksesuarların doğru yerlere yerleştirilip yerleştirilmediğini kontrol ediniz.

Sorun	Olası neden
Kapı contasında kaçak var.	<ul style="list-style-type: none"> • Kapı contası üzerindeki yabancı maddeleri temizleyiniz. • Kapı contasının eski biçimini kazanması için önce ısıtıp ardından soğutunuz (ya da elektrikli bir kurutucu ile hava üfleyiniz ya da sıcak bir havlu kullanarak ısıtınız).
Su kabı taşıyor.	<ul style="list-style-type: none"> • Bölme içinde çok fazla yiyecek var ya da saklanan yiyeceklerin su içeriği çok fazla ve bu durum yoğun buz çözme işlemine neden oluyor. • Kapılar düzgün kapanmıyor, bu da içeri hava girmesi nedeniyle buzlanmaya ve buz çözme işlemi nedeniyle de su taşmasına neden oluyor.
Gövdede ısınma var.	<ul style="list-style-type: none"> • Üründeki kondansatörün gövde aracılığıyla ısı yayması normal bir durumdur. Ortam sıcaklığının yüksek olması, dolap içine çok fazla yiyecek konulması ya da kompresörün durması nedeniyle gövdede ısınma söz konusu olur, ısı yayılımını sağlamak için yeterli havalandırma sağlayınız.
Yüzeyde yoğuşma var.	<ul style="list-style-type: none"> • Ortamdaki nem oranı çok yüksek olduğunda buzdolabının dış yüzeyinde ve kapı contalarında yoğuşma meydana gelmesi normal bir durumdur. Yoğuşma suyunu temiz bir havluyla silerek gidermeniz yeterlidir.
Anormal gürültü	<ul style="list-style-type: none"> • Vızıltı: Kompresör çalıştığı sırada vızıltı sesi çıkarabilir ve bu vızıltılar özellikle başlama ya da durma sırasında daha çok işitilir. Bu normal bir durumdur. • Gıcırıtı: Cihazın içinde dolaşan soğutucu akışkan gıcırıtı sesi çıkarır ve bu normal bir durumdur.

simfer

DOUBLE DOOR 294L SR-2515



TOP MOUNTED FREEZER REFRIGERATOR INSTRICUTION MANUAL

Please read and save all instructions to ensure safe and effective use of this Appliance

CONTENTS

SAFETY WARNINGS- -----	21
PRODUCT OVERVIEW -----	23
PRODUCT INSTALLATION -----	24
OPERATION INSTRUCTIONS-----	30
CLEANING AND MAINTENANCE-----	33
TROUBLESHOOTING -----	35

1 Safety warnings

1.1 Warning



Warning: risk of fire / flammable materials

This appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail applications.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

The appliance has to be unplugged after use and before carrying out user maintenance on the appliance.

Warning: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

Warning: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

Warning: Do not damage the refrigerant circuit.

Warning: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

Warning: Please abandon the refrigerator according to local regulators for its use flammable blowing gas and refrigerant.

Warning: When positioning the appliance, ensure the supply cord is not trapped or damaged.

Warning: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

Do not use extension cords or ungrounded (two prong) adapters.

Danger: Risk of child entrapment. Before you throw away your old refrigerator or freezer:

–Take off the doors.

–Leave the shelves in place so that children may not easily climb inside.

The refrigerator must be disconnected from the source of electrical supply before attempting the installation of accessory.

Refrigerant and cyclopentane foaming material used for the appliance are flammable. Therefore, when the appliance is scrapped, it shall be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm.

The necessity that, for doors or lids fitted with locks and keys, the keys be kept out of the reach of children and not in the vicinity of the refrigerating appliance, in order to prevent children from being locked inside .

For EU standard: This appliance can be used by children aged from 8 years and above and persons with reduce physical sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.

To avoid contamination of food, please respect the following instructions:

- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
 - Clean regularly surfaces that can come in contact with food and accessible drainage systems.
 - Clean water tanks if they have not been used for 48 h; flush the water system connected to a water supply if water has not been drawn for 5 days. (note 1)
 - Store raw meat and fish in suitable containers in the refrigerator, so that it is not in contact with or drip onto other food.
 - Two-star frozen-food compartments are suitable for storing pre-frozen food, storing or making ice-cream and making ice cubes. (note 2)
 - One-, two- and three-star compartments are not suitable for the freezing of fresh food. (note 3)
 - For appliances without a 4-star compartment: this refrigerating appliance is not suitable for freezing foodstuffs. (note 4)
 - If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.
- Note 1,2,3,4: Please confirm whether it is applicable according to your product compartment type.

For a freestanding appliance: this refrigerating appliance is not intended to be used as a built-in appliance.

Any replacement or maintenance of the LED lamps is intended to be made by the manufacturer, its service agent or similar qualified person. (See chapter 2.4 for lamp replacement)

Warning: To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.

Warning: Connect to potable water supply only. (Suitable for ice making machine)

To Prevent A Child From Being Entrapped, Keep Out Of Reach Of Children And Not In The Vicinity Of Freezer (Or Refrigerator). (Suitable for products with locks)




WARNING: Risk of fire / flammable material

Refrigerant and cyclopentane foaming material used for the appliance are flammable. Therefore, when the appliance is scrapped, it shall be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm

PRODUCT OVERVIEW

Names of components



- | | | | |
|---|---------------------------|---|-----------------|
| 1 | Freezer Shelf | 4 | Small Door tray |
| 2 | Refrigerator Shelf | 5 | Big Door tray |
| 3 | Fruits and vegetables box | | |

ATTENTION

The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor

PRODUCT INSTALLATION

Install Instruction


For refrigerating appliances with climate class

- Depending on the climate class, This refrigerating appliance is intended to be used at ambient temperatures range as specified following table.
- The product may not operate properly at temperatures outside of the specific range.
- You can find the climate class on the product label.

Class	Symbol	Ambient temperature range °C	
		IEC 62552 (ISO 15502)	ISO 8561
Extended temperate	SN	+ 10 to + 32	+ 10 to + 32
Temperate	N	+ 16 to + 32	+ 16 to + 32
Subtropical	ST	+ 16 to + 38	+ 18 to + 38
Tropical	T	+ 16 to + 43	+ 18 to + 43

Dimensions and Clearances


- Too small of a distance from adjacent items may result in the degradation of freezing capability and increased electricity costs. the refrigerator both sides should be placed against the wall with a free distance more than 100mm, and the refrigerator back against the wall distance not more than 75 mm.



ATTENTION

The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor

Space requirement diagram (when the door is open and when the door is closed)







Width	Overall Height	Depth	Depth Only Cabinet	Width doors open 135°	Depth doors open 135°
A	B	C	C1	D	E
595	1760	550	470	991	975

Notice: All dimensions in mm

Door right-left change

List of tools to be provided by the user

	Allen wrench-Cross screwdriver
	Putty knife Thin-blade screwdriver
	5/16" socket spanner
	Masking tape

Parts to be used for door reverse

SN	Parts	Quantity
1	Right upper hinge	1
2	Right upper hinge cover	1
3	Upper hinge axle sleeve	1
4	Upper hinge screw	3
5	Hole cover	1
6	Middle hinge screw	2
7	Middle hinge	1
8	Hole plug	2
9	Middle beam screw	1
10	Middle beam screw cap	1
11	Adjustable foot	1
12	Lower hinge screw	3
13	Lower hinge assembly	1
14	Lower end cover screw of freezing door	1
15	Lower end cover limiting block of freezing door	1
16	Lower end cover screw of refrigerator door	1
17	Lower end cover limiting block of refrigerator door	1
18	Upper end cover axle sleeve of refrigerator door	1
19	Lower support of refrigeration door	1
20	Accessory package	4
21	Self-locking of right door	1


Notes:

1-19/Pre-installed on the refrigerator and to be used when changing the door


20/Left upper hinge,left upper hinge cover,Self-locking of left door,left decorative cover

21/Pre-installed on refrigerator, removed and retained it when changing the door


1. Please power off this appliance before conduct this operation.
2. Dismantle upper hinge cover, upper hinge and hole cap of the other side, and then remove the freezer door.




1. Dismantle the middle hinge, the screw hole caps and remove the refrigerating door.




2. Dismantle the bottom hinge, hole caps and screws, install the bottom hinge shaft and adjust foot on other side of the bottom hinge, then install the hinge on the other side.




1. Dismantle the screw, sleeve pipe and stopper from the refrigerating door and freezer door, and the support on the lower cover of the refrigerating door is also removed.
2. Then install them on the other side of the doors in order.
3. Exchange the position of sleeve pipe and hole cap at the top cover of refrigerating door, and install the upper hinge sleeve on the freezer door to the hole on the other side of axis sleeve.



4. Put the cold door on the lower hinge , install the middle hinge, cover, screw and screw cap.



5. Put the refrigerating door on the middle hinge , install the upper hinge, hinge cover and hole cap.



Leveling feet

To avoid vibration, the appliance must be leveled.

If required, adjust the leveling feet to compensate for the uneven floor.

The front should be slightly higher than the rear to aid in door closing.

Leveling feet can be turned easily by tipping the cabinet slightly.

Turn the leveling feet counter clockwise  to raise the unit, clockwise  to lower it.

Power the appliance


After installing the product, please let it stay for more than 2 hours before turning on the power, otherwise it will lead to a decrease in cooling capacity or a damage to the product.

Tips for energy saving

- Do not place the appliance near cookers, radiators or other heat sources. If the ambient temperature is high, the compressor will run more frequently and for longer, resulting in increased energy consumption.
- Ensure that there is sufficient ventilation at the base of the appliance, on the sides of the appliance and at the back of the appliance.
- Please also observe the spacing dimensions in the chapter “Installation”.
- The arrangement of drawers, shelves and trays as shown in the product overview offers the most efficient use of energy and should be retained as far as possible.
- To obtain a larger storage space (e.g. for large refrigerated/frozen goods), the middle drawers and shelves can be removed. The top and bottom drawers and shelves should be removed last if necessary.
- An evenly filled refrigerator/freezer compartment contributes to optimal energy use.
- Allow warm food to cool before placing it in the refrigerator/freezer compartment. Food that has already cooled down increases energy efficiency.
- Allow frozen food to defrost in the refrigeration compartment. The coldness of the frozen food reduces the energy consumption in the refrigerator compartment and thus increases the energy efficiency.
- Open the door only as briefly as necessary to minimise cold loss. Opening the door briefly and closing it properly reduces energy consumption.
- Setting the temperature no colder than necessary contributes to optimal energy use.
- The door gaskets of your appliance must be perfectly intact so that the doors close properly and energy consumption is not increased unnecessarily.

OPERATION INSTRUCTIONS

Control Knob



- Turn the temperature control knob to MAX, the internal temperature of the refrigerator becomes lower.
- Turn the temperature control knob to MIX, the internal temperature of the refrigerator becomes higher.
- Please adjust the temperature between "MAX" and "MIN".
- When the knob is turned to "DEFROST", it means that the compressor stops running.

Tips on storing food

Freezer compartment





- The freezer compartment is designated for the low-temperature freezing of food, long-term storage of frozen food, and for the production of ice cubes.
- Pay attention to the star classifications (4 star, 2 star and 1 star) in the freezer compartment and the resulting storage periods for frozen food.
- Do not put fresh and frozen food next to each other. The frozen food may thaw.
- When freezing large amounts of fresh food (such as meat, fish or chopped meat), please divide them into several small pieces before putting in, so that they can be quickly frozen and pick up easily.
- Abide by the storage times recommended by food manufacturers on the packages, there is no information on the packaging, food should not be stored frozen for longer than three months from the date of purchase.
- When purchasing frozen food, make sure that it was frozen at a suitable temperature and that the packaging is not damaged.
- Frozen food should be kept in suitable individual packages to ensure that adjacent food cannot be contaminated. Consume thawed and defrosted foods immediately, do not refreeze them.
- In case of prolonged power failure or malfunction of the appliance, remove the stored frozen food and check whether they are still edible, then store them in a sufficiently cool place or in another appliance.
- To defrost food, remove it from the freezer and let it defrost at room temperature or in the refrigerator. To defrost food quickly, you can use the defrost function on your microwave, for example.
- If you only want to defrost part of a pack, remove the portion you need and immediately close the rest of the pack. In this way, you will avoid “freezer burn” and will reduce ice formation on the remaining foods.

Cooling compartment

- To reduce moisture and subsequent ice build-up, never put liquid into the fridge compartment in unsealed containers. Frost tends to concentrate in the coolest parts of the evaporator. Storing uncovered liquids results in a more frequent need for defrosting.
- Never put warm foods in the fridge compartment. These should first cool down at room temperature and then be placed so as to ensure adequate air circulation in the fridge compartment.
- Foods or food containers should not touch the back wall of the fridge because they could freeze to the wall. Do not keep regularly opening the door of the refrigerator.
- Meat and clean fish (packed in a package or plastic foil) can be placed in the fridge compartment, which can be used in 1-2 days.
- Fruit and vegetables without packaging can be placed in the part designated for fresh fruit and vegetables

ATTENTION

The optimal temperature setting of each compartment depends on the ambient temperature. Above optimal temperature is based on the ambient temperature of 25 °C.

Order	Compartments TYPE	Target storage temp. [°C]	Appropriate food
1	Fridge	$+2 \leq x \leq +8$	Eggs, cooked food, packaged food, fruits and vegetables, dairy products, cakes, drinks and other foods are not suitable for freezing.
2	 Four-star rating frozen	$x \leq -18$	With freezing capacity, fast freezing speed, can quickly freeze and store food. Suitable for frozen fresh food such as seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products. Recommended for 3 ~ 6 months, the longer the storage time, the worse the taste and nutrition.
3	 Three-star rating frozen	$x \leq -18$	With freezing capacity. Suitable for frozen fresh food such as seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products. Recommended no more than 3 months.
4	 Two-star rating frozen	$x \leq -12$	Only suitable for medium-term storage of already frozen food, e.g. ice cream. Recommended no more than 1 month.
5	 One-star rating frozen	$x \leq -6$	Only suitable for refrigeration, and short-term storage of small quantities of already frozen food. Recommended no more than 1 week.
6	0-star	$-6 \leq x \leq 0$	Fresh pork, beef, fish, chicken, some packaged processed foods, etc. (Recommended to eat within the same day, preferably no more than 3 days). Partially encapsulated processed foods (non-freezable foods).
7	Chill	$-2 \leq x \leq +3$	Fresh/ frozen pork, beef, chicken, freshwater aquatic products, etc. (7 days below 0°C and above 0°C is recommended for consumption within that day, preferably no more than 2 days). Seafood less than 0 for 15 days, it is not recommended to store above 0°C.
8	Fresh food	$0 \leq x \leq +4$	Fresh pork, beef, fish, chicken, cooked food, etc. (Recommended to eat within the same day, preferably no more than 3 days)

ATTENTION

Please note the manufacturer instructions on the packaging. Please store different foods according to the compartments or target storage temperature of your purchased.


CLEANING AND MAINTENANCE

Defrosting

- Power off the refrigerator. remove the food from the refrigerator and place it properly to prevent food from melting.
- Clear the drain pipe (to use soft materials to prevent damage to the liner), Prepare the water containers for defrosting. (pay attention to clean the compressor compartment water draining tray, Ovoding overflow to the ground).
- You can also use the appropriate amount of hot water to speed up the defrost, with a dry towel to dry the water after defrosting.
- You can also use the appropriate amount of hot water to speed up the defrost, with a dry towel to dry the water after defrosting.
- After defrosting, put back the foods in cabinet, and power on the refrigerator.


Cleaning of door tray

- According to the direction arrow in the figure, use both hands to squeeze the tray, and push it upward, then you can take it out.
- After cleaning the door tray, place the tray into the slot on the door and press down until it is in place. On some model products you can adjust its installing height.




Cleaning of glass shelf

- As the innermost part of the refrigerator liner where contacting the shelves has a backstop, you shall slightly lift up the rear side of the shelf, then to take it out.
- After cleaning the glass shelve, place the shelve horizontally on the rails and push inwards until the backstop into the slot. On some model products you can adjust its installing height.



Cleaning the drawer

- Remove the contents of the drawer. Hold the handle of the drawer and pull it out completely until it stops.
- Lift the drawer up and remove it out.



Stop using

Power failure:

In case of power failure, even if it is in summer, foods inside the appliance can be kept for several hours; during the power failure, the times of door opening shall be reduced, and no more fresh food shall be put into the appliance.

Long-time nonuse:

The appliance shall be unplugged and then cleaned; then the doors are left open to prevent odor.

Moving:

Before the refrigerator is moved, take all objects inside out, fix the glass partitions, vegetable holder, freezing chamber drawers and etc. with tape, and tighten the leveling feet; close the doors and seal them with tape. During moving, the appliance shall not be laid upside down or horizontally, or be vibrated; the inclination during movement shall be no more than 45°.



CAUTION

The appliance shall run continuously once it is started. Generally, the operation of the appliance shall not be interrupted; otherwise the service life may be impaired.

Foods can be preserved for a couple of hours even in summer in case of power failure; it is recommended to reduce the frequency of opening door.

TROUBLESHOOTING

The following simple issues can be handled by the user. Please call the after-sale service department if the issues are not solved.

Problem	Possible reason
Failed operation	<ul style="list-style-type: none"> • Check whether the appliance is connected to power or whether the plug is in well contact
	<ul style="list-style-type: none"> • Check whether the voltage is too low
	<ul style="list-style-type: none"> • Check whether there is a power failure or partial circuits have tripped
Odor	<ul style="list-style-type: none"> • Odorous foods shall be tightly wrapped
	<ul style="list-style-type: none"> • Check whether there is any rotten food
	<ul style="list-style-type: none"> • Clean the inside of the refrigerator
Long-time operation of the compressor	<ul style="list-style-type: none"> • Long operation of the refrigerator is normal in summer
	<ul style="list-style-type: none"> • when the ambient temperature is high It is not suggestible having too much food in the appliance at the same time
	<ul style="list-style-type: none"> • Food shall get cool before being put into the appliance
	<ul style="list-style-type: none"> • The doors are opened too frequently
Light fails to get lit	<ul style="list-style-type: none"> • Check whether the refrigerator is connected to power supply and whether the illuminating light is damaged
	<ul style="list-style-type: none"> • Have the light replaced by a specialist
Door can not be properly closed	<ul style="list-style-type: none"> • The door is stuck by food packages Too much food is placed
	<ul style="list-style-type: none"> • The refrigerator is tiltedr.
Loud noises	<ul style="list-style-type: none"> • Check whether the floor is level and whether the refrigerator is placed stably
	<ul style="list-style-type: none"> • Check whether accessories are placed at proper locations

Problem	Possible reason
Door seal fails to be tight	<ul style="list-style-type: none"> • Remove foreign matters on the door seal • Heat the door seal and then cool it for restoration (or blow it with an electrical drier or use a hot towel for heating)
Water pan overflows	<ul style="list-style-type: none"> • There is too much food in the chamber or food stored contains too much water,resulting in heavy defrosting • The doors are not closed properly, resulting in frosting due to entry of air and increased water due to defrosting
Hot housing	<ul style="list-style-type: none"> • Heat dissipation of the built-in condenser via the housing, which is normal When housing becomes hot due to high ambient temperature, storage of too much food or shutdown of the compressor is shut down, provide sound ventilation to facilitate heat dissipation
Surface condensation	<ul style="list-style-type: none"> • Condensation on the exterior surface and door seals of the refrigerator is normal when the ambient humidity is too high. Just wipe the condensate with a clean towel.
Abnormal noise	<ul style="list-style-type: none"> • Buzz: The compressor may produce buzzes during operation, and the buzzes are loud particularly upon start or stop. This is normal. • Creak: Refrigerant flowing inside of the appliance may produce creak, which is normal.

APPENDIX

Special for new European standard

The ordered parts in the following table can be acquired from Service provider channel

Ordered part	Provided by	Minimum time required for Provision
Thermostats	Professional maintenance personnel	At least 7 years after the last model is launched on the market
Temperature sensors	Professional maintenance personnel	At least 7 years after the last model is launched on the market
Printed circuit boards	Professional maintenance personnel	At least 7 years after the last model is launched on the market
Light sources	Professional maintenance personnel	At least 7 years after the last model is launched on the market
Door handles	Professional repairers and final users	At least 7 years after the last model is launched on the market
Door hinges	Professional repairers and final users	At least 7 years after the last model is launched on the market
Trays	Professional repairers and final users	At least 7 years after the last model is launched on the market
Baskets	Professional repairers and final users	At least 7 years after the last model is launched on the market
Door gaskets	Professional repairers and final users	At least 10 years after the last model is launched on the market

Dear customer

1. If you want to return or replace the product, please contact the store where you buy.

(Remember to bring the purchase invoice)

2. If your product breaks down which needs to repair, please contact after-sales service provider.

ATTENTION

The model information in the product database, as well as the model identifier, can be obtained through a weblink scanned by a QR code, if any, on the energy efficiency label of the product.

For more information about the energy efficiency of the appliance, visit <https://ec.europa.eu> and search using the model name.

The model name can be found on the rating label of the appliance.