


Buzdolabı Kullanma Kılavuz



ÇİFT KAPILI
SR-2516

TR-ENG

simfer

İÇİNDEKİLER

1	Güvenlik uyarıları	
1.1	Uyarı	2-3
1.2	Güvenlik uyarı sembollerinin anlamları	4
1.3	Elektrikle ilgili uyarılar	4
1.4	Kullanım uyarıları	5
1.5	Yerleştirme için uyarılar	5
1.6	Enerji için uyarılar	6
1.7	İmha için uyarılar	6
2	Buzdolabının uygun şekilde kullanımı	
2.1	Yerleştirme	8
2.2	Dengeleme ayakları	8
2.3	Kapı Sağ-Sol Değişimi (Opsiyonel)	8
2.4	Işığın Değiştirilmesi (Opsiyonel)	13
2.5	Başlangıç	13
2.6	Enerji tasarrufu ipuçları	13
3	Yapısı ve işlevleri	
3.1	Temel bileşenler	14
3.2	İşlevleri	15
4	Buzdolabının bakım ve onarımı	
4.1	Genel temizlik	16
4.2	Cam rafın temizlenmesi	16
4.3	Buz çözme	16
4.4	Faaliyet dışı	17
5	Sorun Giderme	18
6	Parametreler	19

1 Güvenlik Uyarıları

1.1 Uyarı



Uyarı: yangın riski / yanıcı maddeler

BU cihaz, mağazalardaki, ofislerdeki ve diğer çalışma ortamlarındaki personel mutfak alanları; çiftlik evleri ve otellerdeki, motellerdeki ve diğer konut tipi ortamlardaki müşteriler tarafından; yatak ve kahvaltı tipi ortamlar; catering ve benzeri perakende olmayan uygulamalar gibi ev ve benzeri uygulamalarda kullanılmak üzere tasarlanmıştır.

BU cihaz, güvenliklerinden sorumlu bir kişi tarafından gözetim altında tutulmadıkları veya cihazın kullanımıyla ilgili talimat verilmediği sürece, fiziksel, duyuşsal veya zihinsel yetenekleri sınırlı olan veya deneyim ve bilgi eksikliği olan kişiler (çocuklar dahil) tarafından kullanılmak üzere tasarlanmamıştır).

EĞER besleme kablosu hasar görürse, bir tehlikeyi önlemek için üretici, servis temsilcisi veya benzer kalifiye kişiler tarafından değiştirilmelidir.

YANICI itici gaz içeren aerosol kutuları gibi patlayıcı maddeleri bu cihazda saklamayın.

KULLANIMDAN sonra ve cihaz üzerinde kullanıcı bakımı yapmadan önce cihazın fişini çekilmelidir.

UYARI: Cihaz muhafazasındaki veya ankastre yapıdaki havalandırma açıklıklarını engellerden uzak tutun.

UYARI: Buz çözme işlemini hızlandırmak için üretici tarafından tavsiye edilenler dışında mekanik cihazlar veya başka araçlar kullanmayın.

UYARI: Soğutucu gaz devresine zarar vermeyin.

UYARI: Üretici tarafından tavsiye edilen tipte olmadıkça, cihazın gıda saklama bölmelerinin içinde elektrikli aletler kullanmayın.

UYARI: Yanıcı üfleme gazı ve soğutucu gaz kullanması nedeniyle lütfen buzdolabını yerel regülatörlere uygun olarak bırakın.

UYARI: Cihazı yerleştirirken, besleme kablosunun sıkışmadığından veya hasar görmediğinden emin olun.

UYARI: Cihazın arkasına birden fazla taşınabilir priz veya taşınabilir güç kaynağı yerleştirmeyin.

UZATMA kabloları veya topraklanmamış (iki uçlu) adaptörler kullanmayın.

TEHLİKE: Çocuk sıkışması riski. Eski buzdolabınızı veya dondurucunuzu atmadan önce:

- Kapıları çıkarın.

CİHAZ için kullanılan soğutucu akışkan ve siklopentan köpük malzemesi yanıcıdır. Bu nedenle, cihaz hurdaya çıkarıldığında, herhangi bir ateş kaynağından uzak tutulmalı ve çevreye zarar vermesini veya başka herhangi bir zararı önlemek için yanma yoluyla imha edilmesinin dışında ilgili niteliklere sahip özel bir geri kazanım şirketi tarafından geri kazanılmalıdır.

ÇOCUKLAR, cihazla oynamadıklarından emin olmak için gözetim altında tutulmalıdır.

EN standardı için: Bu cihaz, 8 yaş ve üzeri çocuklar ve fiziksel duyuşsal veya zihinsel yetenekleri azalmış veya deneyim ve bilgi eksikliği olan kişiler tarafından, cihazın güvenli bir şekilde kullanılmasına ilişkin gözetim veya talimat verildiği ve ilgili tehlikeleri anladıkları takdirde kullanılabilir. Çocuklar cihaz ile oynamamalıdır. Temizlik ve kullanıcı bakımı gözetim olmadan çocuklar tarafından yapılmamalıdır. 3 ila 8 yaş arası çocukların soğutucu cihazları yüklemelerine ve boşaltmalarına izin verilir.

Gıdaların kontaminasyonunu önlemek için lütfen aşağıdaki talimatlara uyun:

- Kapağın uzun süre açılması, cihazın bölmelerindeki sıcaklığın önemli ölçüde artmasına neden olabilir.
- Gıda ile temas edebilecek yüzeyleri ve erişilebilir drenaj sistemlerini düzenli olarak temizleyin.
- Su tanklarını 48 saat boyunca kullanılmamışlarsa temizleyin; 5 gün boyunca su çekilmemişse bir su kaynağına bağlı su sistemini yıkayın. (not 1)
- Çiğ et ve balığı, diğer yiyeceklerle temas etmeyecek veya üzerine damlamayacak şekilde buzdolabında uygun kaplarda saklayın.
- İki ** yıldızlı dondurulmuş gıda bölmeleri önceden dondurulmuş gıdaları saklamak, dondurma saklamak veya yapmak ve buz küpleri yapmak için uygundur. (not 2)
- Bir *, iki ** ve üç *** yıldızlı bölmeler taze gıdaların dondurulması için uygun değildir (not 3)
- Soğutucu cihaz uzun süre boş bırakılırsa, cihaz içinde küf oluşumunu önlemek için kapatın, buzunu çözün, temizleyin, kurulaşın ve kapıyı açık bırakın.

Not 1,2,3: Lütfen ürün bölmesi tipinize göre geçerli olup olmadığını onaylayın.




UYARI: Cihazın dengesizliğinden kaynaklanan bir tehlikeyi önlemek için, talimatlara uygun olarak sabitlenmelidir.

UYARI: Sadece içilebilir su kaynağına bağlayın. (Buz yapma makinesi için uygundur)

Bir Çocukun Sıkışmasını Önlemek İçin, Çocukların Ulaşamayacağı Yerde Tutun ve Dondurucunun (Veya Buzdolabının) Çevresinde Bulundurmayın." (Kilitli ürünler için uygundur)


Bu ürün, enerji verimlilik sınıfı (F) olan bir ışık kaynağı içerir.

1.2 Güvenlik uyarı sembollerinin anlamı


	<p>Bu bir yasaklama sembolüdür. Bu sembole işaretlenmiş talimatlara uyulmaması ürünün hasar görmesine veya kullanıcının kişisel güvenliğinin tehlikeye girmesine neden olabilir.</p>
	<p>Bu bir uyarı sembolüdür. Bu sembole işaretlenmiş talimatlara tam olarak uyularak çalıştırılması gerekir; aksi takdirde üründe hasar veya kişisel yaralanma meydana gelebilir.</p>
	<p>Bu bir dikkat sembolüdür. Bu sembole işaretlenmiş talimatlar özel dikkat gerektirir. Yetersiz dikkat hafif veya orta derecede yaralanmaya veya ürünün hasar görmesine neden olabilir.</p>

Bu kılavuz, kullanıcılar tarafından uyulması gereken birçok önemli güvenlik bilgisi içermektedir.


1.3 Elektrikle ilgili uyarılar




- Buzdolabının elektrik fişini çekerken güç kablosunu çekmeyin. Lütfen fişi sıkıca kavrayın ve doğrudan prizden çekin.
- Güvenli kullanım sağlamak için güç kablosuna zarar vermeyin veya güç kablosunu hasarlı veya yıpranmış halde kullanmayın.



- Lütfen özel bir elektrik prizi kullanın ve elektrik prizi diğer elektrikli cihazlarla paylaşılmamalıdır. Elektrik fişi prize sıkıca temas ettirilmelidir, aksi takdirde yangın çıkabilir.
- Lütfen elektrik prizinin topraklama elektrodunun güvenilir bir topraklama hattı ile donatıldığından emin olun.




- Gaz ve diğer yanıcı gazların sızması durumunda lütfen sızan gazın vanasını kapatın ve ardından kapı ve pencereleri açın. Kıvılcımın yangına neden olabileceğini düşünerek buzdolabının ve diğer elektrikli cihazların fişini çekmeyiniz.



- Üretici tarafından tavsiye edilen tipte olmadıkça, elektrikli aletleri cihazın üstünde kullanmayın.

1.4 Kullanımı ile ilgili uyarılar



- Buzdolabını gelişigüzel sökmeyin veya tekrar kurmayın ya da soğutucu akışkan devresine zarar vermeyin; cihazın bakımı bir uzman tarafından yapılmalıdır
- Hasarlı güç kablosu, tehlikeyi önlemek için üretici, bakım departmanı veya ilgili profesyoneller tarafından değiştirilmelidir.



- Buzdolabı kapıları arasındaki ve kapılar ile buzdolabı gövdesi arasındaki boşluklar küçüktür, parmağınızın sıkışmasını önlemek için elinizi bu alanlara koymamaya dikkat edin. Eşyaların düşmesini önlemek için buzdolabının kapısını kapatırken lütfen nazik olun.
- Buzdolabı çalışırken dondurma bölümündeki yiyecekleri veya kapıları, özellikle donmayı önlemek için metal kapıları ıslak ellerle almayınız.




- Hiçbir çocuğun buzdolabına girmesine veya tırmanmasına izin vermeyin; aksi takdirde çocuğun boğulmasına veya düşerek yaralanmasına neden olabilir.




- Kapıyı kapatırken veya açarken nesnelerin düşebileceğini ve kazara yaralanmalara neden olabileceğini göz önünde bulundurarak buzdolabının üstüne ağır nesnelere koymayın.
- Elektrik kesintisi veya temizlik durumunda lütfen fişi çekin. Arka arkaya çalıştırma nedeniyle kompresörün zarar görmesini önlemek için buzdolabını beş dakika içinde güç kaynağına bağlamayın.


1.5 Yerleştirme ile ilgili uyarılar



- Ürünün zarar görmesini veya yangın kazalarını önlemek için buzdolabına yanıcı, patlayıcı, uçucu ve yüksek derecede aşındırıcı maddeler koymayın.
- Yangınları önlemek için yanıcı maddeleri buzdolabının yakınına koymayın.



- Buzdolabı, gıdaların saklanması gibi ev kullanımı için tasarlanmıştır; kan, ilaç veya biyolojik ürünlerin saklanması gibi başka amaçlar için kullanılmamalıdır.



- Şişelerde veya kapalı kaplarda bulunan bira, meşrubat veya diğer sıvıları buzdolabının dondurma bölümünde saklamayın; aksi takdirde şişeler veya kapalı kaplar donma nedeniyle çatlayarak hasara neden olabilir.

1.6 Enerji ile ilgili uyarılar

Enerji ile ilgili uyarı

- 1) Soğutucu cihazlar, soğutucu cihazın tasarlandığı sıcaklık aralığının soğuk ucunun altına uzun bir süre yerleştirildiğinde tutarlı çalışmayabilir (içindekilerin buzunun çözülmesi veya donmuş gıda bölümünde sıcaklığın çok yükselmesi olasılığı).
- 2) Köpüren içeceklerin gıda dondurucu bölmelerinde veya dolaplarında veya düşük sıcaklık bölmelerinde veya dolaplarında saklanmaması gerektiği ve su buzları gibi bazı ürünlerin çok soğuk tüketilmemesi gerektiği gerçeği;
- 3) Gıda dondurucu ve dondurulmuş gıda saklama bölmelerinde veya dolaplarında her türlü gıda için ve özellikle ticari olarak hızlı dondurulmuş gıdalar için gıda üreticileri tarafından önerilen saklama sürelerinin aşılması gerektiği;
- 4) Dondurulmuş gıdanın birkaç kat gazete kağıdına sarılması gibi, soğutucu cihazın buzunu çözerken dondurulmuş gıdanın sıcaklığının aşırı yükselmesini önlemek için gerekli önlemler.
- 5) Manuel buz çözme, bakım veya temizlik sırasında dondurulmuş gıdanın sıcaklığındaki artışın saklama ömrünü kısaltabileceği gerçeği.
- 6) Kilit ve anahtarlarla donatılmış kapı veya kapaklarda, çocukların içeride kilitli kalmasını önlemek için anahtarların çocukların erişemeyeceği bir yerde ve soğutucu cihazın yakınında bulundurulması gerekliliği.

1.7 İmha ile ilgili uyarılar

Buzdolabı için kullanılan soğutucu akışkan ve siklopentan köpük malzemesi yanıcıdır. Bu nedenle, buzdolabı hurdaya çıkarıldığında, herhangi bir ateş kaynağından uzak tutulmalı ve çevreye zarar vermesini veya başka herhangi bir zararı önlemek için yakılarak imha edilmesi dışında uygun niteliklere sahip özel bir kazanım şirketi tarafından geri kazanılmalıdır.




Buzdolabı hurdaya çıkarıldığında, kapıları sökün ve kapı ve rafların contasını çıkarın; kapıları ve rafları herhangi bir çocuğun sıkışmasını önleyecek şekilde uygun bir yere koyun.




Bu ürünün Doğru İmhası:


Bu işaret, bu ürünün diğer evsel atıklarla birlikte atılmaması gerektiğini gösterir. Kontrolsüz atık imhasının çevreye veya insan sağlığına olası zararlarını önlemek için, malzeme kaynaklarının sürdürülebilir yeniden kullanımını teşvik etmek amacıyla sorumlu bir şekilde geri dönüştürün. Kullanılmış cihazınızı iade etmek için lütfen iade ve toplama sistemlerini kullanın veya ürünün satın alındığı perakendeciye iletişime geçin. Bu ürünün çevresel açıdan güvenli geri dönüşüm için alabilirler.




- Kullanmadan önce, buzdolabının içindeki alt yastıklar, köpük pedler ve bantlar dahil olmak üzere tüm ambalaj malzemelerini çıkarın; kapılar ve buzdolabı gövdesi üzerindeki koruyucu filmi yırtın.



- Isıdan uzak tutun ve doğrudan güneş ışığından kaçının. Paslanmayı veya yalıtım etkisinin azalmasını önlemek için dondurucuyu nemli veya sulu yerlere yerleştirmeyin.
- Buzdolabının elektrik yalıtım özelliklerini etkilememek için buzdolabını püskürtmeyin veya yıkamayın; buzdolabını su sıçraması kolay nemli yerlere koymayın.



- Buzdolabı iyi havalandırılan kapalı bir yere yerleştirilir; zemin düz ve sağlam olmalıdır (dengesizse tekerleği düzleştirmek için sola veya sağa döndürerek ayarlayın).



- Buzdolabının üst boşluğu 10 cm'den fazla olmalı, ısı dağılımını kolaylaştırmak için buzdolabı her iki tarafta 10 cm'den fazla serbest mesafeye sahip bir duvara yerleştirilmeli ve cihazların arkası 7,5 cm'yi aşmayan bir serbest mesafeye sahip bir duvara yerleştirilmelidir

Kurulumdan önce alınacak önlemler:




Aksesuarları takmadan veya ayarlamadan önce buzdolabının elektrik bağlantısının kesildiğinden emin olunmalıdır.

Tutamağın düşerek herhangi bir kişisel yaralanmaya neden olmasını önlemek için önlemler alınmalıdır.

2.2 Dengeleme ayakları

Dengeleme ayaklarının şematik diyagramı



(Yukarıdaki resim sadece referans içindir. Gerçek konfigürasyon fiziksel ürüne veya distribütör tarafından yapılan açıklamaya bağlı olacaktır)

Ayarlama prosedürleri:


- Buzdolabını yükseltmek için ayakları saat yönünde çevirin;
- Buzdolabını indirmek için ayakları saat yönünün tersine çevirin;
- Yukarıdaki prosedürlere göre sağ ve sol ayakları yatay bir seviyeye ayarlayın.

2.3 Kapının Sağa Sola Değişimi (Opsiyonel)


Kullanıcı tarafından tedarik edilecek aletlerin listesi			
	Alyan anahtarı Yıldız tornavida		Macun bıçağı ince uçlu tornavida
	5116" soket ve mandal		Maskeleme bandı

Kapının ters çevrilmesi için kullanılacak parçalar			
SN	parçalar	Miktar	Notlar
1	Sağ üst menteşe	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
2	Sağ üst menteşe kapağı	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
3	Üst menteşe aks kovanı	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
4	Üst menteşe vidası	3	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
5	Delik kapağı	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
6	Orta menteşe vidası	2	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
7	Orta menteşe	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
8	Delik tapası	2	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
9	Orta giriş vidası	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
10	Orta giriş vidalı kapağı	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
11	Ayarlanabilir ayak	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
12	Alt menteşe vidası	3	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
13	Alt menteşe grubu	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
14	Dondurucu kapağının alt uç kapak vidası	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak
15	Alt uç kapağı dondurucu kapağının sınırlayıcı bloğu	1	Buzdolabına önceden monte edilmiş ve kapı değiştirilirken kullanılacak


- 1) Bu işlemi yapmadan önce lütfen bu cihazı kapatın.
- 2) Kutunun sağ üst tarafındaki menteşe kapağını ve vidasını, ayrıca sol taraftaki üst menteşeyi ve delik kapağını çıkarın.




- 3) Menteşe vidasını sökün, orta menteşeyi ve üst mil kovanını çıkarın, orta menteşe üzerindeki iki menteşe deliği kapağını (tapa pimleri) ayırın ve buzdolabı bölmesinin kapı gövdesini yukarı doğru çıkarın.




4) Menteşe milini ve mil kovanını alt menteşenin sol deliğine ve ardından alt menteşeyi buzdolabının sol köşesine, ardından Şekilde gösterilen konuma göre ayar ayağı A'yı ve son olarak ayar ayağı B'yi buzdolabının sağ alt köşesine takın.




Montajı tamamladıktan sonra.




5) İki kapı gövdesinin kapı durdurucusunu ve sağ kapının kendinden kilitlemeli vidalarını sökün, ardından aksesuar çantasından sol kapının kendinden kilitlemesini çıkarın ve kapı durdurucusuyla birlikte kapı gövdesinin sol köşesine takın; soğutma odası kapı gövdesinin alt destek bloğunu çıkarın ve sol alt köşeye takın, son olarak soğutma odası kapısı için delik tapasını ve mil kovanını çıkarın ve konumlarını ayarlayın ve ardından bunları kapı gövdesine takın. Soğutma odasının kapısındaki sağ dekoratif kapığı çıkarın ve aksesuar çantasından sol dekoratif kapığı çıkarıp takın.




6) Buzdolabı bölmesinin kapısını alt menteşeye, buzdolabının sol tarafındaki orta menteşeye takın ve vidaları sıkın ve mil kovanını iyice yerleştirin. Tapa pimini diğer uçtaki orta kiriş üzerindeki deliğe takın.




7) Dondurucu kapađını orta menteşeye takın, sol üst menteşeyi ve sol üst menteşe kapađını aksesuar çantasından çıkarın, sol menteşeyi takın ve vidaları sıkın, sol üst menteşe kapađını takın ve vidayı sıkın, sađ sensörü orijinal sol delik kapađına takın ve ardından delik kapađını sađ kutuya sabitleyin.



8) Kurulumu tamamladıktan sonra







2.4 Işıđı Deđiřtirme (Opsiyonel)




- LED lambaların herhangi bir şekilde deđiřtirilmesi veya bakımının üretici, servis temsilcisi veya benzeri kalifiye bir kiři tarafından yapılması amaçlanmıřtır.


Bu üründeki ışık kaynađı yalnızca kalifiye mühendisler tarafından deđiřtirilebilir.

1		1. Lütfen çıkarmadan önce fiři çıkarın.	2		Abajuru bir tornavida ile çıkarın.
3		3. Lamba panelini ařađı indirin.	4		4. Bađlantı terminalini çıkarın.

2.5 Çalıřtırma



- İlk çalıřtırmadan önce, güç kaynađına bađlamadan önce buzdolabını iki saat hareketsiz tutun.
- Herhangi bir taze veya dondurulmuř gıda koymadan önce, buzdolabı 2-3 saat veya ortam sıcaklıđının yüksek olduđu yaz aylarında 4 saatten fazla çalıřmıř olmalıdır.




- Kapıların ve çekmecelerin rahatça açılabilmesi veya distribütör tarafından beyan edilebilmesi için yeterli alan ayırın.

2.6 Enerji tasarrufu ipuçları

- Cihaz odanın en serin yerine, ısı üreten aletlerden veya ısıtma kanallarından uzađa ve doğrudan güneř ışıđından uzak bir yere yerleřtirilmelidir.
- Sıcak yiyecekleri cihaza yerleřtırmekten önce oda sıcaklıđına sođumasını bekleyin. Cihazın aşırı yüklenmesi kompresörü daha uzun süre çalıřmaya zorlar. Çok yavař donan gıdalar kalitesini kaybedebilir veya bozulabilir.
- Gıdaları cihaza yerleřtırmekten önce düzgün bir şekilde sardıđınızdan ve kapları kuruladıđınızdan emin olun. Bu, cihazın içinde don birikmesini azaltır.
- Cihaz saklama bölmesi alüminyum folyo, yađlı kađıt veya kađıt havlu ile kaplanmamalıdır. Astarlar sođuk hava dolařımını engelleyerek cihazın daha az verimli olmasını sađlar.
- Kapı açıklıklarını ve uzun aramaları azaltmak için yiyecekleri düzenleyin ve etiketleyin. Tek seferde gerektiđi kadar ürünü çıkarın ve kapıyı mümkün olan en kısa sürede kapatın.

3 Yapısı ve işlevleri

3.1 Temel bileşenler



(Yukarıdaki resim sadece referans içindir. Gerçek konfigürasyon fiziksel ürüne veya distribütör tarafından yapılan açıklamaya bağlı olacaktır)


Soğutucu bölme

- Soğutucu Bölme, kısa vadede tüketilen çeşitli meyve, sebze, içecek ve diğer yiyeceklerin saklanması için uygundur.
- Pişirilen gıdalar oda sıcaklığına soğuyana kadar soğutucu bölmeye konulmamalıdır.
- Gıdaların buzdolabına konulmadan önce kapatılması tavsiye edilir.
- Cam raflar, makul miktarda saklama alanı ve kolay kullanım için yukarı veya aşağı ayarlanabilir.
-

Dondurucu bölme

- Düşük sıcaklıktaki dondurma haznesi gıdaları uzun süre taze tutabilir ve esas olarak dondurulmuş gıdaları saklamak ve buz yapmak için kullanılır.
- Dondurma bölmesi et, balık, pirinç topları ve kısa vadede tüketilmeyecek diğer gıdaların saklanması için uygundur.
- Et parçaları tercihen hızlı dondurma ve kolay erişim için küçük parçalara bölünmelidir. Lütfen yiyeceklerin raf süresi içinde tüketilmesi gerektiğini unutmayın.

3.2 İşlevleri



(Yukarıdaki resim sadece referans içindir. Gerçek konfigürasyon fiziksel ürüne veya distribütör tarafından yapılan açıklamaya bağlı olacaktır)

1) Anahtar

A. Soğutucu bölmesinin sıcaklık ayar düğmesi

2) Görüntüleme ekranı

1 ayar 1: SOĞUK

2 ayar 2: ■

3 ayar 3: EN SOĞUK

4 Ayar 4: SÜPER SOĞUK

3) Ekran


Buzdolabına ilk kez elektrik verildiğinde, ekran 3 saniye boyunca tamamen parlak ve ardından buzdolabı ayar 3'e göre çalışır. Bir arıza durumunda, ilgili LED yanıp söner. Herhangi bir arıza olmaması durumunda, buzdolabının sıcaklık ayarını gösterir.

Hata Kodu	Hata Tanımı
Gösterge ayarı 4 ve ayar 3	Buzdolabı sıcaklık sensörü
Gösterge ayarı 4 ve ayar 2	Dondurucu buz çözme sensörü
Gösterge ayarı 4 ve ayar 1	Ortam sıcaklık sensörü

4) Sıcaklık ayarı

Sıcaklık ayar düğmesi A'ya her basıldığında sıcaklık ayarı bir kez değişir. Sıcaklık ayarı tamamlandıktan sonra, buzdolabı 15 saniye sonra ayarlanan değere göre çalışacaktır.

Vardiya düzenlemesi:



5) Kilitleme/Kilit Açma

Sıcaklık kontrol paneli kilitli durumdayken, sıcaklık ayar tuşuna uzun süre basılması gerekir

Panelin kilidini açmak için 3 saniye boyunca, panel kilidi açıldığında tüm LED'ler 2 saniye boyunca yanıp sönecektir. Sıcaklık kontrol paneli kilit açma durumundayken, 15 saniye içinde kontrol panelinde herhangi bir işlem yapılmazsa, otomatik olarak kilit durumuna geçecektir.

6) Damper ayar sürgüsü



4. Cihazın bakım ve onarımı

4.1 Genel temizlik


- Soğutma etkisini iyileştirmek ve enerji tasarrufu sağlamak için buzdolabının arkasındaki ve yerdeki tozlar zamanında temizlenmelidir.
- Kalıntı olmadığından emin olmak için kapı contasını düzenli olarak kontrol edin. Kapı contasını sabunlu su veya seyreltilmiş deterjanla ıslatılmış yumuşak bir bezle temizleyin.
- Kokuyu önlemek için buzdolabının içi düzenli olarak temizlenmelidir.
- Lütfen iç kısmı temizlemeden önce gücü kapatın, tüm yiyecekleri, içecekleri, rafları, çekmeceleri vb. çıkarın.
- Buzdolabının içini temizlemek için iki yemek kaşığı karbonat ve bir litre ılık su ile yumuşak bir bez veya sünger kullanın. Ardından suyla durulayın ve silerek temizleyin. Temizlikten sonra kapıyı açın ve gücü açmadan önce doğal olarak kurummasını bekleyin.
- Buzdolabında temizlenmesi zor alanlar için (dar sandviçler, boşluklar veya köşeler gibi), bu alanlarda kirletici veya bakteri birikmemesini sağlamak için yumuşak bir bez, yumuşak fırça vb. ile ve gerektiğinde bazı yardımcı araçlarla (ince çubuklar gibi) birlikte düzenli olarak silinmesi önerilir.
- Sabun, deterjan, ovma tozu, sprey temizleyici vb. kullanmayın, çünkü bunlar buzdolabının iç kısmında kokuya veya kirlenmiş yiyeceklere neden olabilir.
- Şişe çerçevesini, rafları ve çekmeceleri sabunlu su veya seyreltilmiş deterjanla ıslatılmış yumuşak bir bezle temizleyin. Yumuşak bir bezle kurulayın veya doğal yollarla kurutun.
- Buzdolabının dış yüzeyini sabunlu su, deterjan vb. ile ıslatılmış yumuşak bir bezle silin ve ardından kurulayın.
- Buzdolabının yüzeyine ve iç kısmına zarar verebilecek sert fırçalar, temiz çelik bilyeler, tel fırçalar, aşındırıcılar (diş macunları gibi), organik çözücüler (alkol, aseton, muz yağı vb.), kaynar su, asit veya alkali maddeler kullanmayın. Kaynar su ve benzen gibi organik çözücüler plastik parçaları deforme edebilir veya zarar verebilir.
- Kısa devreleri önlemek veya daldırma sonrasında elektrik yalıtımını etkilememek için temizlik sırasında doğrudan su veya diğer sıvılarla durulamayın.



Buz çözme ve temizleme için lütfen buzdolabının fişini çekin.

4.2 Cam rafın temizlenmesi

- Cam raf üzerindeki çekmeceyi çıkarın;
- Cam rafın önünü yukarı kaldırın ve ardından dışarı çekin;
- Cam rafı çıkarın ve gerektiği gibi temizleyin;
- Ters işlem cam rafın montajı içindir.



4.3 Buz çözme

- Buzdolabı hava soğutma prensibine göre üretilmiştir ve bu nedenle otomatik buz çözme fonksiyonuna sahiptir. Mevsim veya sıcaklık değişimine bağlı olarak oluşan buzlanma, cihazın güç kaynağıyla bağlantısı kesilerek veya kuru bir havluyla silinerek manuel olarak da giderilebilir.

4.4 Faaliyet dışı

- Elektrik kesintisi: Elektrik kesintisi durumunda, yaz aylarında olsa bile, cihazın içindeki yiyecekler birkaç saat saklanabilir; elektrik kesintisi sırasında, kapı açma süreleri azaltılacak ve cihaza daha fazla taze yiyecek konulmayacaktır.
- Uzun süre kullanılmaması: Cihazın fişi çekilmeli ve ardından temizlenmelidir; daha sonra kokuyu önlemek için kapılar açık bırakılır.
- Taşınma: Buzdolabı taşınmadan önce, içindeki tüm nesnelere çıkarılmalı, cam bölmeler, sebzelik, dondurucu bölme çekmeceleri vb. bantla sabitlenmeli ve dengeleme ayakları sıkılmalıdır; kapılar kapatılmalı ve bantla kapatılmalıdır. Taşıma sırasında cihaz baş aşağı veya yatay olarak yatırılmamalı veya titreştirilmemelidir; hareket sırasında eğim 45°'den fazla olmamalıdır.



Cihaz çalıştırdıktan sonra sürekli olarak çalışmalıdır. Genel olarak, cihazın çalışması kesintiye uğratılmamalıdır; aksi takdirde kullanım ömrü bozulabilir

5 Sorun giderme

5.1 Aşağıdaki basit sorunları kendi başınıza çözmeyi deneyebilirsiniz. Eğer çözemerseniz, lütfen satış sonrası departmanı ile iletişime geçin.

Hatalı işlem	Cihazın elektriğe bağlı olup olmadığını veya fişin iyi temas edip etmediğini kontrol edin. Voltajın çok düşük olup olmadığını kontrol edin. Elektrik kesintisi olup olmadığını veya kısmi devrelerin atıp atmadığını kontrol edin.
Koku	Kokulu gıdalar sıkıca sarılmalıdır. Çürümüş gıda olup olmadığını kontrol edin. Buzdolabının içini temizleyin.
Kompresörün uzun süre çalışması	Ortam sıcaklığının yüksek olduğu yaz aylarında buzdolabının uzun süre çalışması normaldir. Cihazda aynı anda çok fazla yiyecek bulunması tavsiye edilmez. Yiyecekler cihaza konulmadan önce soğumalıdır. Kapılar çok sık açılıyor.
Işık yanmıyor	Buzdolabının güç kaynağına bağlı olup olmadığını ve aydınlatma ışığının hasarlı olup olmadığını kontrol edin..
Kapılar düzgün şekilde kapatılmıyor	Kapı yiyecek paketleri tarafından sıkıştırılmış. Buzdolabı eğiktir.
Yüksek ses	Zeminin düz olup olmadığını ve buzdolabının dengeli yerleştirilip yerleştirilmediğini kontrol edin. Aksesuarların uygun yerlere yerleştirilip yerleştirilmediğini kontrol edin..
Kapı contası sıkı değil	Kapı contası üzerindeki yabancı maddeleri temizleyin. Kapı contasını ısıtın ve ardından onarmak için soğutun (veya elektrikli bir kurutucu ile üfleyin veya ısıtmak için sıcak bir havlu kullanın).
Su kabı taşıyor	Haznede çok fazla yiyecek var veya depolanan yiyecek çok fazla su içeriyor, bu da ağır buz çözmeye neden oluyor. Kapılar düzgün kapatılmamıştır, bu da hava girişi nedeniyle buzlanmaya ve buz çözme nedeniyle artan suya neden olur.
Sıcak konut	Yerleşik kondansatörün muhafaza yoluyla ısı yayması normaldir. Yüksek ortam sıcaklığı ve çok fazla gıda depolanması nedeniyle muhafaza ısındığında, ısı dağılımını kolaylaştırmak için sağlam havalandırma sağlanması önerilir.
Yüzey yoğuşması	Ortam nemi çok yüksek olduğunda buzdolabının dış yüzeyinde ve kapı contalarında yoğuşma olması normaldir. Yoğuşma suyunu temiz bir havluyla silmeniz yeterlidir

Tablo 1 İklim Sınıfları

Sınıf	Sembol	Ortam sıcaklık aralığı °C
Genişletilmiş ılıman	SN	+ 10 ila + 32
ılıman	N	+ 16 ila + 32
Subtropikal	ST	+ 16 ila + 38
Tropikal	T	+ 16 ila + 43

Genişletilmiş ılıman:'bu soğutucu cihaz 10 °C ila 32 °C arasındaki ortam sıcaklıklarında kullanılmak üzere tasarlanmıştır';

ılıman:'bu soğutucu cihaz 16 °C ila 32 °C arasındaki ortam sıcaklıklarında kullanılmak üzere tasarlanmıştır';

Subtropikal:'bu soğutucu cihaz 16 °C ila 38 °C arasındaki ortam sıcaklıklarında kullanılmak üzere tasarlanmıştır';

Tropikal:'bu soğutucu cihaz 16 °C ila 43 °C arasındaki ortam sıcaklıklarında kullanılmak üzere tasarlanmıştır';

Yeni Avrupa standardı için özel:

Aşağıdaki tabloda sipariş edilen parçalar aşağıdaki kanaldan temin edilebilir _:

Sipariş Edilen Parçalar	Tedarik eden	Tedarik için Gerekli Minimum Süre
termostatlar	Profesyonel bakım personeli	Son modelin piyasaya sürülmesinden en az 7 yıl sonra piyasaya sürüldü
sıcaklık sensörleri	Profesyonel bakım personeli	Son modelin piyasaya sürülmesinden en az 7 yıl sonra piyasaya sürüldü
baskılı devre kartları	Profesyonel bakım personeli	Son modelin piyasaya sürülmesinden en az 7 yıl sonra piyasaya sürüldü
ışık kaynakları	Profesyonel bakım personeli	Son modelin piyasaya sürülmesinden en az 7 yıl sonra piyasaya sürüldü
kapı kolları	Profesyonel tamirciler ve son kullanıcılar	Son modelin piyasaya sürülmesinden en az 7 yıl sonra piyasaya sürüldü
Tepsiler	Profesyonel tamirciler ve son kullanıcılar	Son modelin piyasaya sürülmesinden en az 7 yıl sonra piyasaya sürüldü
Sepetler	Profesyonel tamirciler ve son kullanıcılar	Son modelin piyasaya sürülmesinden en az 7 yıl sonra piyasaya sürüldü
kapı contaları	Profesyonel tamirciler ve son kullanıcılar	Son modelin piyasaya sürülmesinden en az 10 yıl sonra
kapı menteşeleri	Profesyonel tamirciler ve son kullanıcılar	Son modelin piyasaya sürülmesinden en az 10 yıl sonra

- Satış sonrası yedek parça temini için en kısa süre 15 iş günüdür.
- Ürün veri tabanındaki model bilgileri ve model tanımlaması, ürün enerji verimliliği etiketi üzerindeki QR kod (varsa) üzerindeki web bağlantısı taranarak elde edilebilir.

Sevgili Müşteri

1. Ürünü iade etmek veya değiştirmek istiyorsanız, lütfen satın aldığınız mağaza ile iletişime geçin. (Satın alma faturasını getirmeyi unutmayın)
2. Ürününüz arızalanırsa ve onarılması gerekiyorsa, lütfen satış sonrası servis sağlayıcısına başvurun.

simfer

**DOUBLE DOOR 413L
SR-2516**



TOP MOUNTED FREEZER REFRIGERATOR INSTRICUTION MANUAL

Please read and save all instructions to ensure safe and effective use of this Appliance

CONTENTS

1 Safety warnings	
1.1 Warning	22
1.2 Meanings of safety warning symbols	24
1.3 Electricity related warnings	24
1.4 Warnings for using	25
1.5 Warnings for placement	25
1.6 Warnings for energy	26
1.7 Warnings for disposal	26
2 Proper use of the refrigerator	
2.1 Placement	27
2.2 Levelling feet	28
2.3 Door Right-Left Change(Optional)	29
2.4 Changing the Light(Optional)	33
2.5 Starting	33
2.6 Energy saving tips	33
3 Structure and functions	
3.1 Key components	34
3.2 Functions	35
4 Maintenance and care of the refrigerator	
4.1 Overall cleaning	36
4.2 Cleaning the glass shelf	36
4.3 Defrosting	36
4.4 Out of operation	37
5 Trouble shooting	38
6 Parameters	39

1 Safety Warnings

1.1 Warning



Warning: risk of fire / flammable materials

THIS appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail applications.

THIS appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.)

IF the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

DO not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

THE appliance has to be unplugged after use and before carrying out user maintenance on the appliance.

WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

WARNING: Do not damage the refrigerant circuit.

WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

WARNING: Please abandon the refrigerator according to local regulators for its use flammable blowing gas and refrigerant.

WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.

WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

DO not use extension cords or ungrounded (two prong) adapters.

DANGER: Risk of child entrapment. Before you throw away your old refrigerator or freezer:
- Take off the doors.





REFRIGERANT

and cyclopentane foaming material used for the appliance are flammable. Therefore, when the appliance is scrapped, it shall be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm.

CHILDREN should be supervised to ensure that they do not play with the appliance.

FOR EN standard: This appliance can be used by children aged from 8 years and above and persons with reduce physical sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.

TO avoid contamination of food , please respect the following instructions:

- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- Clean regularly surfaces that can come in contact with food and accessible drainage systems.
- Clean water tanks if they have not been used for 48 h; flush the water system connected to a water supply if water has not been drawn for 5 days. (note 1)
- Store raw meat and fish in suitable containers in the refrigerator, so that it is not in contact with or drip onto other food.
- Two-star  frozen-food compartments are suitable for storing pre-frozen food, storing or making ice-cream and making ice cubes. (note 2)
- One , two -and three-star  compartments are not suitable for the freezing of fresh food. (note 3)
- If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.

Note 1,2,3: Please confirm whether it is applicable according to your product compartment type.




WARNING: To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.

WARNING: Connect to potable water supply only. (Suitable for ice making machine)

TO Prevent A Child From Being Entrapped, Keep Out Of Reach Of Children And Not In The Vicinity Of Freezer (Or Refrigerator)." (Suitable for products with locks)


This product contains a light source of energy efficiency class (F).

1.2 Meaning of safety warning symbols


 Prohibition symbol	This is a prohibition symbol. Any incompilance with instructions marked with this symbol may result in damage to the product or endanger the personal safety of the user.
 Warning symbol	This is a warning symbol. It is required to operate in strict observance of instructions marked with this symbol; or otherwise damage to the product or personal injury may be caused.
 Note symbol	This is a cautioning symbol. Instructions marked with this symbol require special caution. Insufficient caution may result in slight or moderate injury, or damage to the product.

This manual contains lots of important safety information which shall be observed by the users.

1.3 Electricity related warnings.




- Do not pull the power cord when pulling the power plug of the refrigerator. Please firmly grasp the plug and pull out it from the socket directly.
- To ensure safe use, do not damage the power cord or use the power cord when it is damaged or worn.



- Please use a dedicated power socket and the power socket shall not be shared with other electrical appliances. The power plug should be firmly contacted with the socket or else fires might be caused.
- Please ensure that the grounding electrode of the power socket is equipped with a reliable grounding line.




- Please turn off the valve of the leaking gas and then open the doors and windows in case of leakage of gas and other flammable gases. Do not unplug the refrigerator and other electrical appliances considering that spark may cause a fire.




- Do not use electrical appliances on the top of the appliance, unless they are of the type recommended by the manufacturer.

1.4 Warnings for using



- Do not arbitrarily disassemble or reconstruct the refrigerator, nor damage the refrigerant circuit; maintenance of the appliance must be conducted by a specialist
- Damaged power cord must be replaced by the manufacturer, its maintenance department or related professionals in order to avoid danger.



- The gaps between refrigerator doors and between doors and refrigerator body are small, be noted not to put your hand in these areas to prevent from squeezing the finger. Please be gentle when close the refrigerator door to avoid falling articles.
- Do not pick foods or containers with wet hands in the freezing chamber when the refrigerator is running, especially metal containers in order to avoid frostbite.




- Do not allow any child to get into or climb the refrigerator; otherwise suffocation or falling injury of the child may be caused.



- Do not place heavy objects on the top of the refrigerator considering that objects may fall when close or open the door, and accidental injuries might be caused.
- Please pull out the plug in case of power failure or cleaning. Do not connect the refrigerator to power supply within five minutes to prevent damages to the compressor due to successive starts.


1.5 Warnings for placement



- Do not put flammable, explosive, volatile and highly corrosive items in the refrigerator to prevent damages to the product or fire accidents.
- Do not place flammable items near the refrigerator to avoid fires.



- The refrigerator is intended for household use, such as storage of foods; it shall not be used for other purposes, such as storage of blood, drugs or biological products, etc.



- Do not store beer, beverage or other fluid contained in bottles or enclosed containers in the freezing chamber of the refrigerator; or otherwise the bottles or enclosed containers may crack due to freezing to cause damages.

1.6 Warnings for energy

Warning for energy

- 1) Refrigerating appliances might not operate consistently (possibility of defrosting of contents or temperature becoming too warm in the frozen food compartment) when sited for an extended period of time below the cold end of the range of temperatures for which the refrigerating appliance is designed.
- 2) The fact that effervescent drinks should not be stored in food freezer compartments or cabinets or in low-temperature compartments or cabinets, and that some products such as water ices should not be consumed too cold;
- 3) The need to not exceed the storage time(s) recommended by the food manufacturers for any kind of food and particularly for commercially quick-frozen food in food-freezer and frozen-food storage compartments or cabinets;
- 4) The precautions necessary to prevent an undue rise in the temperature of the frozen food while defrosting the refrigerating appliance, such as wrapping the frozen food in several layers of newspaper.
- 5) The fact that a rise in temperature of the frozen food during manual defrosting, maintenance or cleaning could shorten the storage life.
- 6) The necessity that, for doors or lids fitted with locks and keys, the keys be kept out of the reach of children and not in the vicinity of the refrigerating appliance, in order to prevent children from being locked inside.

1.7 Warnings for disposal

Refrigerant and cyclopentane foaming material used for the refrigerator are flammable. Therefore, when the refrigerator is scrapped, it shall be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm.



When the refrigerator is scrapped, disassemble the doors, and remove gasket of door and shelves; put the doors and shelves in a proper place, so as to prevent trapping of any child.




Correct Disposal of this product:


This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

2 Proper use of refrigerators


2.1 Placement




- Before use, remove all packing materials, including bottom cushions, foam pads and tapes inside of the refrigerator; tear off the protective film on the doors and the refrigerator body.



- Keep away from heat and avoid direct sunlight. Do not place the freezer in moist or watery places to prevent rust or reduction of insulating effect.
- Do not spray or wash the refrigerator; do not put the refrigerator in moist places easy to be splashed with water so as not to affect the electrical insulation properties of the refrigerator.



- The refrigerator is placed in a well-ventilated indoor place; the ground shall be flat, and sturdy (rotate left or right to adjust the wheel for levelling if unstable).



- The top space of the refrigerator shall be greater than 10cm, the refrigerator should be placed against a wall with a free distance more than 10cm on the both side to facilitate heat dissipation, and the back of appliances is intended to be placed against a wall with a free distance not exceeding 7.5 cm


ⓘ Precautions before installation:

Before installation or adjusting of accessories, it shall be ensured that the refrigerator is disconnected from power.

Precautions shall be taken to prevent fall of the handle from causing any personal injury.

2.2 Leveling feet

Schematic diagram of the leveling feet



(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)





Adjusting procedures:

- Turn the feet clockwise to raise the refrigerator;
- Turn the feet counterclockwise to lower the refrigerator;
- Adjust the right and left feet based on the procedures above to a horizontal level.

2.3 Door Right-Left Change (Optional)



List of tools to be provided by the user


	Allen wrench Cross screwdriver		Putty knife thin-blade screwdriver
	5/16" socket and ratchet		Masking tape

Parts to be used for door reverse


SN	Parts	Quantity	Notes
1	Right upper hinge	1	Pre-installed on the refrigerator and to be used when changing the door
2	Right upper hinge cover	1	Pre-installed on the refrigerator and to be used when changing the door
3	Upper hinge axle sleeve	1	Pre-installed on the refrigerator and to be used when changing the door
4	Upper hinge screw	3	Pre-installed on the refrigerator and to be used when changing the door
5	Hole cover	1	Pre-installed on the refrigerator and to be used when changing the door
6	Middle hinge screw	2	Pre-installed on the refrigerator and to be used when changing the door
7	Middle hinge	1	Pre-installed on the refrigerator and to be used when changing the door
8	Hole plug	2	Pre-installed on the refrigerator and to be used when changing the door
9	Middle beam screw	1	Pre-installed on the refrigerator and to be used when changing the door
10	Middle beam screw cap	1	Pre-installed on the refrigerator and to be used when changing the door
11	Adjustable foot	1	Pre-installed on the refrigerator and to be used when changing the door
12	Lower hinge screw	3	Pre-installed on the refrigerator and to be used when changing the door
13	Lower hinge assembly	1	Pre-installed on the refrigerator and to be used when changing the door
14	Lower end cover screw of freezing door	1	Pre-installed on the refrigerator and to be used when changing the door
15	Lower end cover limiting block of freezing door	1	Pre-installed on the refrigerator and to be used when changing the door

1) Please power off this appliance before conduct this operation.


2) Remove the hinge cover and screw on the top right side of the box, as well as the upper hinge and the hole cover on the left side.




3) Unscrew the hinge screw, take off the middle hinge and the upper shaft sleeve, depart the two hinge hole covers (plug pins) on the middle hinge, and take out the door body of the refrigerator chamber upward.




4) Install the hinge shaft and shaft sleeve to the left hole of the lower hinge, and then the lower hinge to the left corner of the refrigerator, then adjusting foot A according to the position shown in the Figure, and finally the adjusting foot B to the right lower corner of the refrigerator.



5) Dismantle the door stop of the two door bodies and the self-locking screws of right door, then take out the self-locking of left door from the accessory bag and install it to the left corner of the door body together with the door stop; take out the bottom support block of the door body of refrigeration chamber and install it to the lower left corner, Finally take out the hole plug and shaft sleeve for the door of refrigeration chamber and adjust their positions, and then install them into the door body.; take out the right decorative cover on the door of refrigeration chamber, and take out the left decorative cover from the accessory bag and install it.



6) Install the door of refrigerator chamber on the lower hinge, the middle hinge on the left side of the refrigerator and tighten the screws, and place the shaft sleeve well. Install the plug pin in the hole on the middle beam at the other end.




7) Install the door of freezer on the middle hinge, take out the left upper hinge and the cover for the left upper hinge from the accessory bag, install the left hinge and tighten the screws, install the cover for the left upper hinge and tighten the screw, install the right sensor in the original left hole cover, and then fix the hole cover on the right box.

Cover for the left upper hinge

Sensor


Left upper hinge

Hole cover



8) After completing the installation

2.4 Changing the Light (Optional)




- Any replacement or maintenance of the LED lamps is intended to be made by the manufacturer, its service agent or similar qualified person.

Light source in this product is replaceable only by qualified engineers.


	<p>1. Please take out the plug before removal.</p>		<p>2. Remove the lampshade with a screwdriver.</p>
	<p>3. Take down the lamp panel.</p>		<p>4. Remove the connection terminal.</p>

2.5 Starting



- Before initial start, keep the refrigerator still for two hours before connecting it to power supply.

- Before putting any fresh or frozen foods, the refrigerator shall have run for 2-3 hours, or for above 4 hours in summer when the ambient temperature is high.




- Spare enough space for convenient opening of the doors and drawers or statement by the distributor.

2.6 Energy saving tips

- The appliance should be located in the coolest area of the room, away from heat producing appliances or heating ducts, and out of the direct sunlight.
- Let hot foods cool to room temperature before placing in the appliance. Overloading the appliance forces the compressor to run longer. Foods that freeze too slowly may lose quality, or spoil.
- Be sure to wrap foods properly, and wipe containers dry before placing them in the appliance. This cuts down on frost build-up inside the appliance.
- Appliance storage bin should not be lined with aluminum foil, wax paper, or paper toweling. Liners interfere with cold air circulation, making the appliance less efficient.
- Organize and label food to reduce door openings and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.

3 Structure and functions

3.1 Key components



(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)


Refrigerating chamber

- The Refrigerating Chamber is suitable for storage of a variety of fruits, vegetables, beverages and other food consumed in the short term.
- Cooking foods shall not be put in the refrigerating chamber until cooled to room temperature.
- Foods are recommended to be sealed up before putting into the refrigerator.
- The glass shelves can be adjusted up or down for a reasonable amount of storage space and easy use.

Freezing chamber

- The low temperature freezing chamber may keep food fresh for a long time and it is mainly used to store frozen foods and making ice.
- The freezing chamber is suitable for storage of meat, fish, rice balls and other foods not to be consumed in short term.
- Chunks of meat are preferably to be divided into small pieces for **for quick freezing and easy access**. Please be noted food shall be consumed within the shelf time.

3.2 Functions



(The picture above is only for reference. The actual configuration will depend on the physical product or statement by the distributor)

1)Key

A. Temperature setting button of refrigerator compartment

2)Display screen

- ① setting 1: COLD
- ② setting 2: ■
- ③ setting 3: COLDEST
- ④ setting 4: SUPER COOL

3)Display


when electrify the refrigerator for first time, the display screen shines fully for 3 seconds, and then the refrigerator runs according to setting 3. In case of a failure, the corresponding LED blinks. In case of no failures, it shows the temperature setting of refrigerator.

Fault Code	Fault Description
Indicator setting 4 and setting 3	Refrigerator temperature sensor
Indicator setting 4 and setting 2	Freezer defrost sensor
Indicator setting 4 and setting 1	Ambient temperature sensor

4)Temperature setting

Each time the temperature setting button A is pressed once, the temperature setting changes one time. After the temperature setting has been completed, the refrigerator will run according to the set value after 15s.


The shift regulation is:



5)Lock/Unlock

When the temperature control panel is in lock state, it needs to long press temperature setting key for 3 seconds for unlocking the panel, all LEDs will blink for 2 seconds when panel is unlocked. When the temperature control panel is in unlock state, if there is no operation on control panel within 15 seconds, it will enter into lock state automatically.

6)Damper adjusting slider



4. Maintenance and care of the refrigerator

4.1 Overall cleaning


- Dusts behind the refrigerator and on the ground shall be timely cleaned to improve the cooling effect and energy saving.
- Check the door gasket regularly to make sure there are no debris. Clean the door gasket with a soft cloth dampened with soapy water or diluted detergent.
- The interior of the refrigerator should be cleaned regularly to avoid odor.
- Please turn off the power before cleaning interior, remove all foods, drinks ,shelves, drawers, etc.
- Use a soft cloth or sponge to clean the inside of the refrigerator, with two tablespoons of baking soda and a quart of warm water. Then rinse with water and wipe clean. After cleaning, open the door and let it dry naturally before turning on the power.
- For areas that are difficult to clean in the refrigerator (such as narrow sandwiches, gaps or corners), it is recommended to wipe them regularly with a soft rag, soft brush, etc. and when necessary, combined with some auxiliary tools (such as thin sticks) to ensure no contaminants or bacterials accumulation in these areas.
- Do not use soap, detergent, scrub powder, spray cleaner, etc., as these may cause odors in the interior of the refrigerator or contaminated food.
- Clean the bottle frame, shelves and drawers with a soft cloth dampened with soapy water or diluted detergent. Dry with a soft cloth or dry naturally.
- Wipe the outer surface of the refrigerator with a soft cloth dampened with soapy water, detergent, etc., and then wipe dry.
- Do not use hard brushes, clean steel balls, wire brushes, abrasives (such as toothpastes), organic solvents (such as alcohol, acetone, banana oil, etc.), boiling water, acid or alkaline items, which may damage the fridge surface and interior. Boiling water and organic solvents such as benzene may deform or damage plastic parts.
- Do not rinse directly with water or other liquids during cleaning to avoid short circuits or affect electrical insulation after immersion.

⚠ Please unplug the refrigerator for defrost and cleaning.



4.2 Cleaning the glass shelf

- Remove the drawer on the glass shelf;
- Lift up the front of glass shelf, and then pull out;
- Remove the glass shelf and clean as needed;
- The reverse operation is for installation of glass shelf.




4.3 Defrosting

- The refrigerator is made based on the air-cooling principle and thus has automatic defrosting function. Frost formed due to change of season or temperature may also be manually removed by disconnection of the appliance from power supply or by wiping with a dry towel.

4.4 Out of operation

- Power failure: In case of power failure, even if it is in summer, foods inside the appliance can be kept for several hours; during the power failure, the times of door opening shall be reduced, and no more fresh food shall be put into the appliance.
- Long-time nonuse: The appliance shall be unplugged and then cleaned; then the doors are left open to prevent odor.
- Moving: Before the refrigerator is moved, take all objects inside out, fix the glass partitions, vegetable holder, freezing chamber drawers and etc. with tape, and tighten the levelling feet; close the doors and fix them with tape. During moving, the appliance shall not be laid upside down or horizontally, or be vibrated; the inclination during movement shall be no more than 45°.

 The appliance shall run continuously once it is started. Generally, the operation of the appliance shall not be interrupted; otherwise the service life may be impaired.

5 Trouble shooting

You may try to solve the following simple problems by yourself. If them cannot be solved, please contact the after-sales department.

Failed operation	<p>Check whether the appliance is connected to power or whether the plug is in well contact .</p> <p>Check whether the voltage is too low.</p> <p>Check whether there is a power failure or partial circuits have tripped.</p>
Odor	<p>Odorous foods shall be tightly wrapped.</p> <p>Check whether there is any rotten food.</p> <p>Clean the inside of the refrigerator.</p>
Long-time operation of the compressor	<p>Long operation of the refrigerator is normal in summer when the ambient temperature is high.</p> <p>It is not recommended having too much food in the appliance at the same time.</p> <p>Food shall get cool before being put into the appliance.</p> <p>The doors are opened too frequently.</p>
Light fails to get lit	<p>Check whether the refrigerator is connected to power supply and whether the illuminating light is damaged.</p>
Doors cannot be properly closed	<p>The door is stuck by food packages.</p> <p>The refrigerator is tilted.</p>
Loud noise	<p>Check whether the floor is level and whether the refrigerator is placed stably.</p> <p>Check whether accessories are placed at proper locations.</p>
Door seal fails to be tight	<p>Remove foreign matters on the door seal.</p> <p>Heat the door seal and then cool it for restoration (or blow it with an electrical drier or use a hot towel for heating).</p>
Water pan overflows	<p>There is too much food in the chamber or food stored contains too much water,resulting in heavy defrosting.</p> <p>The doors are not closed properly, resulting in frosting due to entry of air and increased water due to defrosting.</p>
Hot housing	<p>Heat dissipation of the built-in condenser via the housing, which is normal.</p> <p>When housing becomes hot due to high ambient temperature and storage of too much food,it is recommended to provide sound ventilation to facilitate heat dissipation.</p>
Surface condensation	<p>Condensation on the exterior surface and door seals of the refrigerator is normal when the ambient humidity is too high. Just wipe the condensate with a clean towel.</p>
	<p>Buzz: The compressor may produce buzzes during operation, and the buzzes</p>

Table 1 Climate classes

Class	Symbol	Ambient temperature range °C
Extended temperature	SN	+ 10 to + 32
Temperature	N	+ 16 to + 32
Subtropical	ST	+ 16 to + 38
Tropical	T	+ 16 to + 43

Extended temperature: this refrigerating appliance is intended to be used at ambient temperatures ranging from 10 °C to 32 °C;

temperature: this refrigerating appliance is intended to be used at ambient temperatures ranging from 16 °C to 32 °C;

Subtropical: this refrigerating appliance is intended to be used at ambient temperatures ranging from 16 °C to 38 °C;

Tropical: this refrigerating appliance is intended to be used at ambient temperatures ranging from 16 °C to 43 °C;

Special for new European standard:

The ordered parts in the following table can be acquired from channel _:

Ordered Part	Provided by	Minimum Time Required for Provision
thermostats	Professional maintenance personnel	At least 7 years after the last model is launched on the market
temperature sensors	Professional maintenance personnel	At least 7 years after the last model is launched on the market
printed circuit boards	Professional maintenance personnel	At least 7 years after the last model is launched on the market
light sources	Professional maintenance personnel	At least 7 years after the last model is launched on the market
door handles	Professional repairers and final users	At least 7 years after the last model is launched on the market
door hinges	Professional repairers and final users	At least 7 years after the last model is launched on the market
trays	Professional repairers and final users	At least 7 years after the last model is launched on the market
baskets	Professional repairers and final users	At least 7 years after the last model is launched on the market
door gaskets	Professional repairers and final users	At least 10 years after the last model is launched on the market

- The shortest period for providing after-sales spare parts is 15 working days.
- The model information and model identification in the product database can be obtained by scanning the web link on the QR code (if any) on the product energy efficiency label.

Dear customer

1. If you want to return or replace the product, please contact the store where you buy.
(Remember to bring the purchase invoice)

2. If your product breaks down which needs to repair, please contact after-sales service provider.

Telephone: